MODEL 920 MAGNETIC TAPE TRANSPORT VOLUME I OPERATION AND MAINTENANCE

Cipher Data Products 10225 Willow Creek Road San Diego, California 92131

VOLUME I

TABLE OF CONTENTS

Section		Page No.
1	DESCRIPTION	. 1-1
	GENERAL	
	PURPOSE	. 1-1
	LINDA CIVINIC INTERFECTION LAND INTERALL ATION	. 2-1
II .	UNPACKING, INSPECTION, AND INSTALLATION	
**	GENERAL	
	UNPACKING AND INSPECTION	
	POWER CONNECTION	
	Operating Voltage Selection	
٠.	INITIAL CHECKOUT	
	RACK MOUNTING	. 2-3
	INTERFACE CONNECTIONS	. 2-3
	MULTIPLE TRANSPORT OPERATION	. 2-4
Ш	OPERATION	. 3-1
	GENERAL	. 3-1
	CONTROLS AND INDICATORS	. 3-1
	LOADING TAPE	
	UNLOADING TAPE	
IV	MAINTENANCE	. 4-1
	GENERAL	
	CLEANING	
	Capstan	
	Head and Guides	
•		
	Tape Cleaner	
	Housing	
· .	OPERATING VOLTAGE SELECTION	
	POWER SUPPLY CHECKS AND ADJUSTMENTS	
	Unregulated Voltage Checks	
	Regulated Power Supply Adjustments	4-3

Section		Page No
IV F	REMOVAL AND REPLACEMENT OF PARTS	• 4–5
	Pushbutton/Indicator	
•	Single-Edge Tape Guide	
	Roller Tape Guide	
	Tape Sensor	
	Reel-Hub Grip Ring	
	Reel Hub	
	Head Assembly	
	Capstan	
	Capstan Motor Assembly	
	Vacuum Valve Motor Assembly	
	Vacuum Blower	
	Vacuum Valve Assembly	
	Vacuum Sense Switch Assembly	
	Power Supply Assembly	
	CAPSTAN SERVO ADJUSTMENTS	•
	DC Offset Adjustment	
	Coarse Speed Adjustment	
	Fine Speed Adjustment	
	Alternate Foward and Reverse	
	Fine Speed Adjustments	4-15
•	Ramp Adjustment	
	DUAL MODE DATA BOARD	
	INITIAL SWITCH SETTINGS	4-17
•	READ GAIN AND SKEW ADJUSTMENTS	
	NRZI	4-22
1.34	NRZI Write Skew Verification	
	Phase-Encode Read Gain Verification	
*	Head Azimuth Adjustment	
	CAPACITIVE TRANSDUCER ALIGNMENT	
	MECHANICAL ADJUSTMENTS	
	Tape Path Alignment	
	Reel Hub Adjustment	

Section	· · · · · · · · · · · · · · · · · · ·	Page No.
IV	REPLACEMENT OF ELECTRONIC ASSEMBLIES	. 4-28
	Control/Servo Board	. 4-28
	Dual Mode Data PWB	. 4-28
	File Protect Sensor	. 4-30
	Vacuum Floor/Transducer Assembly	. 4-30
	REMOVAL AND REPLACEMENT OF ELECTRONIC	
	PARTS AND COMPONENTS	. 4-31
	Multiple Lead Components	. 4-31
	Multiple Pin Components	. 4-31
	PROGRAMMING WRITE DESKEW PROM	
	Programming Procedure	. 4-32
٧	TESTING AND TROUBLESHOOTING	. 5-1
	TESTING	. 5-1
	Self Test	. 5-1
	Test Mode Operation	. 5-1
	Diagnostic Mode	. 5-2
	TROUBLESHOOTING	. 5-4
	Troubleshooting Procedure	5-4

LIST OF TABLES

Table No.	P	age No.
1-1	Control/Servo Board Control Option Jumpers	1-2
1-2	Dual-Mode Data Board Control Option Jumpers	1-3
2-1	Interface Connections for Input Commands at Connector J101	2-5
2-2	Interface Connections for Output Commands at Connector J101	2–5
2-3	Interface Connections for Write Inputs at Connector J102	2-6
2-4	Interface Connections for Read Outputs at Connector J103	2-6
3–1	Controls and Indicators	3-3
4-1	Preventive Maintenance Schedule	4-1
4-2	Power Supply Unregulated Voltages	4-3
4-3	Power Supply Regulated Voltages	4-3
4-4	Tape Speed Crystal Frequencies and Switch Settings	4-18
4-5	Switch Settings for Testing and Options	4-19
4-6	Bit Map, Code 23456789	4-23
4-7	Bit Map, Code 77777777	4-23
4-8	Bit Map, Code 6789A987	4-33
5-1	Photo-sensor Functions	5-3
5–2	System Troubleshooting	5- 5

LIST OF ILLUSTRATIONS

Figure No.	Title	Page No.	
3-1	Control Panel	. 3-1	
4-1	Control/Servo PWB Test Point Chart	. 4-4	
4-2	Single-Edge Tape Guide	. 4-6	
4-3	Roller Tape Guide	. 4-7	
4-4	Reel Hub, Showing Adjustment Dimension	. 4-8	
4-5	Head Assembly Adjustments	. 4-10	
4-6	Capstan Removal	. 4-10	
4-7	Replacement Capstan Positioning	. 4-11	
4-8	Strobe Disc	. 4-15	
4-9	Location of Test Points, Pots, Headers, and Switches	. 4-16	
4-10	Ramp Adjustment Traces	. 4-17	
4-11	Skew Pulse at TP10	. 4-22	
4-12	Tape Path Alignment	. 4-26	
4-13	Motor Tilt Procedure	. 4-27	
4-14	Reel Hub Assembly	. 4-28	
4-15	Control/Servo Board Removal	. 4-29	

VOLUME I

SECTION I

DESCRIPTION

GENERAL

- I-I. The dual-mode, 125 ips Model 920 Magnetic Tape Transport is a high-performance, digital, vacuum-buffered tape transport manufactured by Cipher Data Products, Inc., San Diego, California. It has a dual-gap head, providing read-after-write capability, a record overwrite capability, and is designed to operate on 95 to 135 or 190 to 270 Vac, single phase, 49 to 61 Hz line power. It can accommodate reels to 10.5 inches in diameter. Various tape speeds, density capabilities, and options are available, as follows:
 - a. Tape speeds: Standard 125 ips; Optional 75 ips.
 - b. Data densities: 800 bpi (NRZI); 1600 bpi (PE).
 - c. Local density selection.
 - d. Remote density selection.
 - e. Facade color (white is standard).
 - f. Control options (See Tables I-1, I-2 and dual-mode data board switch settings in the Maintenance section).

PURPOSE

I-2. The transport is intended for use in data recording and computer processing systems in which data must be stored on magnetic tape. Writing and reading of digital data are performed in IBM-compatible, NRZI or PE format. Data recorded by a Model 920 transport is completely recoverable by IBM or similar equipment.

FUNCTIONAL TITLE	STANDARD SPECIFICATION	DESCRIPTION OF OPTION	
Transport status indication occur whenever transport is selected. Jumper BC-BD in.		Status indications occur only when transport is selected and on line. Jumper BA-BB in.	
On-line/ready After loss of tape tension (other than due to power failure which requires manual intervention), tape must be rewound to BOT and transport placed online before any remote commands can be executed. No jumper BJ-BK.		*After loss of tape tension, depressing the LOAD switch once; then the ON LINE switch forces the on-line ready status. Jumper BJ-BK in.	
EOT signal	EOT is a pulse. No jumper BS-BT or BW- BY.*	**EOT remains as a level after it has been detected until a re- wind command occurs. Jumper BS-BT or BW-BY in.	
+5 volt provision	+5V is provided on J101, pin S, (for an embedded formatter or Mini-Tex). Jumper AV-AW in.	+5V is not provided on J101, pin S. No jumper AV-AW.	
Density selection	Front panel density selection. Jumper BL-BM or switch I, position I closed.	Fixed PE (high density). Jumpers BE-BF, BG-BH, BL-BM or switch I, positions I, 3 and 4 closed.	
		Fixed NRZI (low density). Jumpers BG-BH, BL-BM or switch I, positions I and 4 closed. Interface density selection.	
		Jumpers BE-BF, BM-BN, or switch I, positions 2 and 3 closed.	
*Available only with EPROM sets 155033-810, 811 revision C (** - rev D) or later.			

Table I-I. Control/Servo Board Control Option Jumpers.

FUNCTIONAL TITLE	STANDARD SPECIFICATION	DESCRIPTION OF OPTION	
Initial density	Transport powers up in NRZI mode. No jumper BP-BR.	*Transport powers up in PE mode. Jumper BP-BR in.	
Rewind/Unload	An off-line command will cause the trans-port to go off-line. No jumper BU-BV.	*An off-line command will cause the trans-port to rewind, unload, and go off-line. Jumper BU-BV in.	
Transport address	Transport address 0. Jumper CH-CJ in.	Transport address I. Jumper CK-CJ in.	
		Transport address 2. Jumper CL-CJ in.	
		Transport address 3. Jumper CM-CJ in.	
* Available only with 811 rev C (** – rev	n EPROM sets 155033-810, v D) or later.		

Table I-I. Control/Servo Board Control Option Jumpers (Continued)

FUNCTIONAL STANDARD TITLE SPECIFICATION		DESCRIPTION OF OPTION
Logic to earth A-B in. Connects data board logic ground to earth ground.		A-B out. Isolates data board logic ground from earth ground.
-15V/-12V to C-D out. Isolates P102 pin 5 -15V/-12V from P102 pin 5.		C-D in. Used only for special systems applications.
P102 pin 5 grounded	D-E in. Connects unused P102 pin 5 to ground.	D-E out. When C-D is installed.
RUN signal F-G in. Data be enables data enables only when land SELECT asserted.		F-G out. Used only for special systems applications.
Select - monitor cable. J-K, L-M, out. Tape drive can be selected if P102 and P103 are not installed.		J-K, L-M, in. Tape drive can be selected only when P102 and P103 are installed.

Table 1-2. Dual-Mode Data Board Control Option Jumpers.

VOLUME I

SECTION II

UNPACKING, INSPECTION, AND INSTALLATION

GENERAL

2-1. This section presents instructions for unpacking, inspecting, and installing the transport.

UNPACKING AND INSPECTION

- 2-2. The transport is shipped in a double container to minimize the possibility of damage during shipping. Unpack as follows:
 - a. With shipping container on floor or workbench, cut side and center tapes securing top of outer box.
 - b. Pull box-top flaps down along sides of box, and turn entire package over on open side of outer box. Lift off outer box and remove packing blocks.

CAUTION

Do not cut center tape of inner box without first cutting side tapes and pulling flaps away from top container. Plastic door of transport can be damaged by failure to observe this precaution.

- c. Cut side tapes securing top of inner box, pull flaps up as far as possible, and cut center tape. Open box, fold flaps back, turn over on open side, and lift off box.
- d. Check contents of shipping container against packing slip, and inspect for visible damage. If damage exists, notify carrier.
- e. Examine vacuum columns, reel hub, capstan, and other components in tape path for foreign matter.
- f. Check printed circuit boards and all connectors for correct installation.

POWER CONNECTION

- 2-3. A removable power cord is supplied for plugging into a polarized 115-volt outlet. For other power sockets, the supplied plug must be removed and the correct plug installed.
- 2-4. OPERATING VOLTAGE SELECTION. The Model 920 can be operated over a wide range of line voltages without changing transformer taps. Four ranges are available: 95 to 110 Vac, 110 to 135 Vac, 190 to 230 Vac, and 230 to 270 Vac. Both a voltage selector, Printed Wire Board (PWB), and the fuse are located in the power cord connector housing mounted in the power supply chassis. One side of the voltage selector PWB has the numbers 120 and 240, each printed upside down from the other, and, on the other side, the numbers 100 and 220 are similarly printed. When line voltage is 95 to 110 volts, the PWB should be plugged in so that number 100 is facing upward and right-side-up to the installer. For 190 to 230 volts, the number should be 220; 110 to 135 volts, number 120; and 230 to 270 volts, number 240. For the 95-to-135-volt ranges, the fuse should be of a 6-ampere rating; for the 190-to-270-volt ranges, a 3-ampere rating.

CAUTION

To prevent damage to the transport and ensure proper operation, be sure the voltage selector PWB and fuse are proper for the power source to be used before applying power to the transport.

INITIAL CHECKOUT

- 2-5. Section III contains a detailed description of all controls. To check for proper transport operation before placing in the system, proceed as follows:
 - a. Connect power cord.
 - b. Clean tape path as directed under cleaning directions.
 - c. Load tape in accordance with instructions in paragraph 3-3.
 - d. Turn power on by pressing POWER switch.
 - e. Momentarily press LOAD switch to apply power to the capstan-motor and reel-motor.
 - f. Momentarily press LOAD switch a second time to initiate load sequence. Tape will move forward until it reaches BOT tab. LOAD indicator should illuminate when BOT tab reaches photosensor and remain illuminated until tape moves off load point. At this point there will be no action when LOAD switch is pressed.
 - g. Check ON LINE switch by pressing repeatedly and observing that ON LINE indicator is alternately illuminated and extinguished.
 - h. With transport off-line (ON LINE indicator not illuminated), press FWD switch. Run several feet of tape onto takeup reel, and press FWD switch again to stop tape.

- i. Check components of tape path visually for correct tape tracking (tape riding smoothly in head, guides, etc.).
- j. Press REV switch. Tape will move backward until BOT tab reaches photosensor, when it will stop.
- k. Check tape tracking as in step i.
- I. Using FWD switch, run several feet of tape on to takeup reel. Press FWD switch again to stop tape. Press REWIND switch momentarily to initiate rewind mode and illuminate REWIND indicator. Tape will rewind to BOT tab and stop with BOT tab at load point. If REWIND switch is momentarily pressed when tape is at BOT, REWIND indicator will be illuminated, and tape will be unloaded from vacuum columns and rewound at low speed. This procedure is used to unload tape. Reel can then be removed.
- m. Make final check of tape tracking, as in step i.

RACK MOUNTING

- 2-6. The transport is designed to be mounted in a standard, 19-inch-wide, RETMA equipment rack. A front panel height of 24 inches and a minimum depth of 12.5 inches behind the mounting surface are required. Note outline dimensions in installation diagram, and mount the transport as follows:
 - Install hinge pin blocks on equipment rack using three 10-32 pan-head screws per hinge. Do not fully tighten screws. Place No. 10 shim washer on each pin.
 - b. Set shipping frame down with front door of transport facing up (i.e., lying in horizontal position). Remove screws securing transport to frame.
 - c. Lift transport out of shipping frame, position 60 degrees from closed position, and hang on hinge pin blocks.
 - d. Adjust hinge blocks on equipment rack so that transport hangs symmetrically in rack. Tighten screws.
 - e. Close tape transport into rack and install safety block, using 4-40 screw.
 - f. Check that adjustable pawl fastener engages behind equipment rack. Adjust if necessary.

INTERFACE CONNECTIONS

- 2-7. Optimally, interconnection of Cipher Data Products and customer equipment should be made with a harness of individual twisted pairs, each with the following characteristics:
 - a. Maximum length of 20 feet.
 - b. Not less than one twist per inch.
 - c. A 24-gauge conductor with minimum insulation thickness of 0.01 inch.

- 2-8. Alternatively, flat ribbon cable can be used, with some signal degradation, in low-noise environments.
- 2-9. It is important that the ground side of each twisted pair be grounded. The mating connectors (ELCO part number 00-6007-036-980-002 or equivalent) must be wired by the customer. Interface signals are routed directly to and from the printed circuit boards. Strain relief should be provided. Tables 2-1 through 2-4 list interface connections.

MULTIPLE TRANSPORT OPERATION

2-10. The Model 920 transport is provided with signal termination. The termination impedance networks are all incorporated in 330 ohm, 220 ohm, and 220/330 ohm resistor packs which plug into integrated circuit sockets. The 220/330 ohm pack is mounted on the data PWB; the other on the control/servo PWB. For multiple transport operation, simply remove the three resistor packs from their sockets on all but the last transport.

LIVE PIN	GRD PIN	SIGNAL
J	8	Select 0 (SLTO)
A	. 8	Select I (SLTI)
18	8	Select 2 (SLT2)
· V	8	Select 3 (SLT3)
С	3	Sync Forward Command (SFC)
E	5	Sync Reverse Command (SRC)
Н	7	Rewind (RWC)
L	10	Off Line (OFFC)
K	9	Set Write Status (WEN)
В	2	Overwrite (OVW)
D __	4	Data Density Select (DDS)

Table 2-1. Interface Connections for Input Commands at Connector J101

LIVE PIN	GRD P i N	SIGNAL
т	16	Ready (RDY)
M	11	On-Line (ONLS)
N	12	Rewinding (RWDG)
U	17	End of Tape (EOT)
R	14	Load Point (LDP)
Р	13	File Protect (FPT)
F	6	Data Density Select (DDI) Indicator
S	-	+5V (Optional)

Table 2-2. Interface Connections for Output Signals at Connector J101

LIVE PIN	GRD PIN	SIGNAL
А		Write Data Strobe (WDS)
C.	3	Write Amplifier Reset (WARS)
F	6	Read Threshold 2 (RTH2)
L	- 10	Write Data Parity (WDP)
M	11	Write Data 0 (WD0)
N	12	Write Data I (WDI)
Р	13	Write Data 2 (WD2)
R	14	Write Data 3 (WD3)
S	. 15	Write Data 4 (WD4)
Т	16	Write Data 5 (WD5)
U	17	Write Data 6 (WD6)
V	18	Write Data 7 (WD7)

Table 2-3. Interface Connections for Write Inputs at Connector J102

LIVE PIN	GRD PIN	SIGNAL
	A	Read Data Parity (RDP)
2	В	Read Data Strobe (RDS) (NRZI only)
3	С	Read Data 0 (RD0)
4	D	Read Data I (RDI)
8	J	Read Data 2 (RD2)
9	К	Read Data 3 (RD3)
10	L	NRZI Transport Indentification (NRZ)
13	Р	Speed ID (ISpeed)
14	R	Read Data 4 (RD4)
15	S	Read Data 5 (RD5)
17	υ	Read Data 6 (RD6)
18	V	Read Data 7 (RD7)

Table 2-4. Interface Connections for Read Outputs at Connector J103

VOLUME I

SECTION III

OPERATION

GENERAL


3-1. This section describes the Model 920 control switches and indicators, and it provides operating instructions.

CONTROLS AND INDICATORS

3-2. Figure 3-1 shows the control switches and indicators. An ON/OFF rocker switch (not shown) is located near the bottom of the control panel. Control/indicator types, functions, and the conditions required for enabling the corresponding functions are given in Table 3-1.

NOTE

The head, capstan, and guide-cleaning procedures described in the Maintenance Section must be performed daily to maintain transport reliability.



920-1

Figure 3-1. Control Panel

LOADING TAPE

- 3-3. To load tape, proceed as follows:
 - a. Pull out reel-locking lever on supply hub. Ensure that tape reel has write enable ring installed if write mode is to be used. Place reel of tape on hub so that tape will unwind when reel is rotated in clockwise direction. Press reel evenly and firmly against hub's back flange and push in locking lever. Spin reel counterclockwise while looking along its rim to ensure even mounting.
 - b. Press ON/OFF switch.
 - c. Thread tape along path shown on facade. Wrap several turns counterclockwise around takeup reel. Check that tape is correctly seated on guides and properly threaded through photosensor and head assembly.

CAUTION

Ensure that tape is positioned correctly on all guides, or tape damage may result.

d. Close front cover to protect tape and transport from dust.

CAUTION

Dust cover must remain closed at all times when tape is on takeup reel. Data reliability may be impaired by contaminants if cover is left open.

e. Press LOAD switch and observe that tape is tensioned, as shown in Figure I-I, and advances until BOT tab is positioned at photosensor. LOAD indicator will illuminate, indicating transport is ready for use.

UNLOADING TAPE

3-4. To unload the tape, proceed as follows:

NOTE

Transport must be in off-line mode (ON LINE indicator off).

- a. If power is off, press POWER switch and proceed to step b. If power is on, start with step c.
- b. Press LOAD switch to tension tape.
- c. Press REWIND switch. REWIND indicator will illuminate. If tape is at load point, tape will be unloaded from vacuum columns and rewound at low speed. If tape is not at load point, rewind ceases when BOT tab is reached. BOT tab is then positioned automatically at photosensor, and LOAD indicator illuminates. Press REWIND switch second time to complete unload sequence.

CONTROL			·
OR INDICATOR	TYPE	FUNCTION	CONDITIONS
POWER	ON/OFF Rocker Switch	Switches line power on and off.	Fuse installed. Line cord connected.
LOAD	Momentary–Action Pushbutton Switch and Indicator	Illuminates to indicate BOT tab is positioned at photosensor.	Power restored af- ter being off. Loss of tape tension.
ON LINE	Momentary– Action Pushbutton Switch and Indicator	Switches transport to on-line mode. Illuminates to indicate transport is on-line.	Initial Load or Rewind actuation. Transport in off-line mode. (ON LINE indicator off.)
		Second actuation switches transport off-line. Indicator off to indicate transport is off-line.	Transport in on-line mode. (ON LINE in- dicator illuminated.)
REWIND	Momentary–Action Pushbutton Switch and Indicator	Rewinds tape to load point. RE-WIND indicator illuminates during rewinding; then goes out.	Transport in off-line mode. (ON LINE indicator off.)
		Load indicator illuminates to indicate BOT is positioned at photosensor.	
		Second actuation of REWIND push-button unloads tape.	
WRT EN (Write Enable)	Indicator	Illuminates to indicate write function may be performed.	Tape reel with write enable ring installed mounted on supply hub.

Table 3-1: Controls and Indicators (Sheet 1 of 2)

CONTROL OR INDICATOR	TYPE	FUNCTION	CONDITIONS
HI DEN (High Density)	Momentary-Action Pushbutton Switch and Indicator	First actuation (indicator ill- uminated): PE mode; second ac- tuation (indicator off): lower den- sity (NRZI) mode.	Transport in off-line mode (ON LINE indicator off).
FORWARD	Pushbutton Switch and Indicator	Starts/stops tape forward motion. Illuminates to indicate transport in forward mode.	Transport in off-line mode (ON LINE indicator off).
REVERSE	Pushbutton Switch and Indicator	Starts/stops tape reverse motion. Illuminates to indicate reverse mode.	Transport in off-line mode (ON LINE indicator off).
TEST	Pushbutton Switch and Indicator	Selects alternate operational mode for other switches.	Transport in off-line mode (ON LINE in- dicator off).

Table 3-1. Controls and Indicators (Sheet 2 of 2)

VOLUME I

SECTION IV

MAINTENANCE

GENERAL

4-1. This section contains periodic maintenance information, removal and replacement instructions, and adjustment procedures. Table 4-1 presents the preventive maintenance schedule.

CAUTION

If transport is to be swung out from equipment rack on hinges for maintenance operations, ensure that the rack is mounted securely. Weight of transport in open position could upset an inadequately mounted equipment rack.

MAINTENANCE OPERATION	FREQUENCY (hours)	QUANTITY TO MAINTAIN	PROCEDURE PARAGRAPH
Clean Head, Guides, Roller Guides, and Capstan Clean Tape Cleaner	daily daily		4-2 4-3 4-4
Check Skew Tape Tracking and Speed	500		4-33 through 4-35, 4-38, 4-25 through 4-28
Replace Reel Motors and Capstan Motor	10,000	3	4-19

Table 4-1. Preventive Maintenance Schedule

CLEANING

4-2. CAPSTAN. For routine capstan cleaning use Freon degreaser, Type TF. (Do not use Freon flux remover.) Wipe the capstan gently, using a lint-free, nonabrasive wipe saturated with Freon. If the capstan is excessively dirty with tape or oxide/binder deposits, it may be cleaned with a Q-tip slightly moistened with Inhibisol (1,1,1 trichloroethane).

CAUTION

Do not clean capstan with motor running. If inhibisol is used, do not touch capstan surface or put tape on capstan for 5 minutes after cleaning, because Inhibisol softens capstan coating temporarily. Do not use head cleaner, Freon flux remover, alcohol, or other solvents to clean capstan sleeves.

4-3. HEAD AND GUIDES. Clean the head, its associated guides, and the roller guides with a lint-free, nonabrasive wipe or a cotton swab moistened with Inhibisol.

CAUTION

Use only Inhibisol to clean head and guides. Rough or abrasive materials can scratch metal parts; other solvents, such as alcohol, or excess solvent can cause increased ISV due to breakdown of bearing lubricant.

- 4-4. TAPE CLEANER. To clean the tape cleaner, use a cotton swab moistened with Freon or Inhibisol and wipe away any accumulated debris clinging to the tape cleaner blades or housing.
- 4-5. HOUSING. The dust door and control panel may be cleaned, as necessary, with a good grade of commercial plastic cleaner.

CAUTION

To prevent permanent scratches, do not use rough or abrasive material to clean the plastic dust door.

OPERATING VOLTAGE SELECTION

- 4-6. The Model 920 can be operated over a wide range of line voltages without changing the transformer taps. Two ranges can be used (95 Vac to 135 Vac and 190 Vac to 270 Vac) simply by changing the voltage selector PWB and the fuse. Both the selector PWB and fuse are located in the power cord connector housing mounted in the power supply chassis.
- 4-7. For the 95-Vac-to-135-Vac range, use a 6-ampere fuse and install the voltage selector PWB so that the number 120 is the only number visible on the board. For the 190-Vac-to-270-Vac range, use a 3-ampere fuse and install the voltage selector PWB so that the number 240 is the only number visible on the board.

CAUTION

To prevent damage to the transport and ensure proper operation, be sure the voltage selector PWB and fuse are proper for the power source to be used before applying power to the transport.

POWER SUPPLY CHECKS AND ADJUSTMENTS

4-8. UNREGULATED VOLTAGE CHECKS. Check unregulated voltages on the power regulation portion of the control/servo PWB. Required values and tolerances are listed in Table 4-2.

NOTE

When checking voltages, ensure that input line voltage is set to the correct value (See the Installation Section).

VOLTAGE TERMINAL	RETURN TERMINAL	REQUIRED READING
J14-4	J14-2	+48(<u>+</u> 15%)V
TP54	TP42-49 (all grounds)	+15(+2.0, -1.0)V

Table 4-2. Power Supply Unregulated Voltages

4-9. REGULATED POWER SUPPLY ADJUSTMENTS. The potentiometer used for this adjustment is located on the power regulator portion of the control/servo PWB. Test point locations are shown in Figure 4-1. Refer to Table 4-3 and for each of the power supplies listed, measure the voltage across the test points.

SUPPLY	TEST	RETURN	ADJUSTMENT	REQUIRED
	POINT	TEST POINT	POT	READING
+5V	TP50	TP42 - 49	R367	+5(±0.05)V
+12V	TP52	TP42 - 49		+12(±0.5)V
-12V -5V +12V	TP53 TP51	TP42 - 49 TP42 - 49	 	-12(±0.5)V -5(±0.25)V
-12V	J7-9 J7-6	TP42 - 49 TP42 - 49		+12(±0.5)V -12(±0.5)V

Table 4-3. Power Supply Regulated Voltages

Figure 4-1. Control/Servo PWB Test Point Chart

REMOVAL AND REPLACEMENT OF PARTS

4-10. Cipher transports are designed to operate for long periods of time without requiring adjustment. In the event a mechanical adjustment is required, return the unit to the Cipher factory, or use the following procedures for removal and replacement of damaged or defective mechanical parts.

WARNING

Before performing any maintenance procedure requiring access to interior of transport, disconnect power cord to eliminate possibility of severe electric shock.

- 4-11. PUSHBUTTON/INDICATOR. The pushbuttons are extremely long-lived, momentary-contact devices, and the indicators are LED's. Both the pushbuttons and LED's are soldered directly into a PWB. Consequently, field repair is impractical, and the complete PWB should be replaced in the event of malfunction. However, individual components are available for service center repair of the PWB. Replace the PWB as follows:
 - a. Remove power cord from back of tape transport.
 - b. Remove brushed aluminum facade from front of switch housing by pulling loose adhesive that holds facade. Discard facade.
 - c. From back of top plate, remove four screws holding switch housing.
 - d. Remove four screws securing switch PWB to switch housing. Unplug switch harness connector from control/servo PWB, feed cable and connector through hole in top plate casting, and withdraw switch PWB assembly.
 - e. Install replacement switch PWB assembly in reverse order of removal.
 - f. Install new brushed aluminum facade. Center openings for pushbutton switches carefully to avoid rubbing or binding.
- 4-12. SINGLE-EDGE TAPE GUIDE. Replace a damaged or worn single-edge tape guide (Figure 4-2) or one of its parts, as follows:
 - a. Loosen three press-lock fasteners and open bottom vacuum column door.
 - b. Remove mounting screw from base plate and disassemble tape guide parts as required.
 - c. Replace defective part, reassemble parts in accordance with Figure 4-2, and secure to base plate with mounting screw. No adjustment is required. Be sure guide mounting surface is free of burrs and debris which could keep guide from seating solidly on machined casting surface. Note that sapphire washer has only one polished surface, which must be the surface against which tape rides.





Figure 4-2. Single-Edge Tape Guide

4-13. ROLLER TAPE GUIDE. The roller tape guide should not require replacement during the life of the tape transport. However, if it becomes necessary to replace a damaged or defective roller guide, the complete assembly must be changed as a unit. Proceed as follows:

- a. Loosen three press-lock fasteners and open side vacuum column door.
- Remove screw securing defective roller guide. Carefully withdraw roller guide, taking care not to drop any small parts or springs.
- c. Using new screw provided with replacement roller guide assembly (discard nut and washer), secure roller guide in position. Take care that the springs are properly positioned, as shown in Figure 4-3, before tightening screw.
- d. No adjustments are required.

920-3



920-4

Figure 4-3. Roller Tape Guide

- 4-14. TAPE SENSOR. The complete EOT/BOT sensor assembly is built and tested as a single unit and must be replaced as such. Remove and replace as follows:
 - a. Unplug electrical connector from control/servo PWB.
 - b. Remove four screws securing head cover to head cover standoffs.
 - c. Remove three screws securing sensor brackets and cable clamp to front of base plate.
 - d. Pull wires and connector carefully through hole provided and remove sensor from base plate.
 - e. Install replacement sensor in reverse order of removal, being careful to mount sensor at correct distance from tape. Face of sensor elements should be 0.150 inch from tape.
 - f. No electrical adjustments are required.
- 4-15. REEL-HUB GRIP RING. Remove and replace the reel-hub grip ring as follows:
 - a. Lift reel look lever to unclamp grip ring.
 - b. Pull old grip ring out of hub groove and remove.

c. Install new grip ring by stretching over reel hub into proper position.

CAUTION

Clean grip ring with Freon degreaser, Type TF only. Alcohol, head cleaner, and other solvents will damage grip ring.

4-16. REEL HUB. Replace and adjust the supply or takeup reel hub as follows (Figure 4-4):

NOTE

Before removing, replacing, and/or adjusting takeup reel, remove attaching screws of surface plate and face plate and lift off plates.

- a. Loosen socket-head screws and remove hub.
- b. Install replacement hub on shaft to obtain dimension shown in Figure 4-4, and tighten socket-head screws.
- c. Mount reel of tape on transport, thread tape, and place transport in load mode.
- d. Run tape forward and reverse, noting tape position on reel for which replacement hub was installed. If necessary, readjust hub height to center tape on reel.




Figure 4-4. Reel Hub, Showing Adjustment Dimension

e. Using right-angle Allen wrench capable of applying 30 inch-pounds of torque, tighten socket-head screws securing hub as tightly as possible.

4-17. HEAD ASSEMBLY. Remove and replace the head assembly in accordance with the following procedure:

NOTE

Hard-faced heads are very sensitive to tape wrap angle. After installing new head, lapping tape may be required for optimum head performance. Lapping tape and complete instructions may be obtained from Cipher by ordering Lapping Tape Kit P/N 154036-101.

- a. Remove four screws securing head cover to head cover standoffs.
- b. Loosen three press-lock fasteners and open bottom vacuum column door.
- c. Unplug head electrical connectors from read/write PWB.
- d. Remove four screws securing head assembly to base plate (Figure 4-5).

NOTE

One of four mounting screws is a small screw inside azimuth screw.

- e. Withdraw head assembly, carefully feeding wires and connectors through hole in base plate.
- f. Feed wires and connectors of replacement head assembly carefully through hole, and secure head assembly to base plate with three sockethead screws not used for azimuth adjustment. Thread outer azimuth adjustment screw into head assembly mount (Figure 4–5), and thread inner azimuth adjustment screw loosely into it.
- g. Make skew adjustment in accordance with paragraphs 4-33 through 4-35.





Figure 4-5. Head Assembly Adjustments

CAPSTAN. Replace a damaged or defective capstan as follows. 4-18.

Screw 1-inch-long, 10-32 NF screw into end of capstan hub until it contacts end of motor shaft. Hold capstan with 1/4-inch open-end wrench (see Figure 4-6), and tighten screw. This will cause capstan sleeve to be pulled from motor shaft.



920-7


920-6

Figure 4-6. Capstan Removal

b. Install replacement capstan over motor shaft until resistance is felt. Insert 1/2-inch-long, 6-32 NC screw through hole in capstan hub, and screw it into threaded hole in motor shaft. Tighten screw until head of screw comes in contact with front of capstan to be pulled onto motor shaft. Tighten screw until capstan is centered evenly in vacuum column opening (see Figure 4-7).

CAUTION

Avoid contact with sensitive tape driving surface of capstan sleeve. Damage to this surface will cause erratic performance and render capstan sleeve useless.



920-8

Figure 4-7. Replacement Capstan Positioning

- c. Mount reel of tape on transport, thread tape, and place in load mode. Check overall capstan performance and adjust if necessary in accordance with paragraph 4-38, steps g through i.
- 4-19. CAPSTAN MOTOR ASSEMBLY. Remove and replace the capstan motor assembly, proceed as follows:
 - a. Disconnect power cord from tape transport.
 - b. Remove capstan sleeve from capstan motor shaft as specified in paragraph 4–18.
 - c. Unplug capstan motor and tachometer connectors from control/servo PWB.
 - d. Remove three screws and motor clamps securing capstan motor to back of machine. Withdraw motor.
 - e. Install replacement capstan motor assembly in reverse order of removal.
 - f. Adjust capstan sleeve height and capstan motor tilt as specified in paragraph 4-18 and paragraph 4-38, steps g through i. Adjust capstan motor speeds, ramp times, and offset as specified in paragraphs 4-25 through 4-29.

- 4-20. VACUUM VALVE MOTOR ASSEMBLY. Remove and replace the vacuum valve motor assembly as follows:
 - a. Disconnect power cord from transport.
 - b. Remove right-side vacuum column floor assembly following procedure presented in paragraph 4-44.
 - c. Unplug valve motor connector from control/servo PWB. Remove contacts from connector housing using Molex Tool No. HT-2038.
 - d. Loosen two setscrews securing valve cord to motor shaft.
 - e. Remove screws, washers, and lockwashers that mount valve motor assembly and withdraw motor assembly. Feed motor cable through grommet, taking care not to damage grommet with sharp contacts.
 - f. Replace valve motor assembly in reverse order or removal. When tightening setscrew make sure valve rotor does not bind or drag against valve housing or housing mounting screw. Note that motor mounting bracket has slotted holes for adjustment.
- 4-21. VACUUM BLOWER. Remove and replace the vacuum blower as follows:
 - a. Disconnect power cord from transport.
 - b. Remove cover from blower mounting bracket.
 - c. Disconnect vacuum blower wires from terminal block and capacitor. Note colors and positions of wires.
 - d. Remove screws, washers, and lockwashers securing vacuum blower to mounting bracket. Support blower securely to prevent it from falling when mounting screws are removed. Install replacement blower in reverse sequence of removal. Be sure to compress rubber/foam gasket between vacuum blower face and top plate to ensure airtight seal.
- 4-22. VACUUM VALVE ASSEMBLY. Remove and replace the vacuum valve assembly as follows:

- a. Remove vacuum blower as specified in paragraph 4-21.
- b. Remove vacuum column floor/transducer assembly as specified in paragraph 4-44.
- c. Loosen two setscrews securing valve cord to valve motor shaft.
- d. Remove two screws, washers and lockwashers securing valve housing to top plate casting, and remove valve assembly.

NOTE

Ensure that valve pin does not slide out of housing. If valve is to be reused, protect it carefully from damage that might cause binding. Clean parts thoroughly before reassembly, using Inhibisol.

- e. Clean RTV sealant off mating surface of top plate.
- f. Install new vacuum valve in reverse sequence of above steps.

CAUTION

To avoid damage and ensure proper operation of transport, when mounting valve housing to top plate, ensure that mating surfaces are free of burrs and other foreign material and that housing is held tightly against top plate surfaces as screws are tightened. Insert valve pin into housing fully before attaching housing to top plate to keep mounting screws from damaging valve rotor.

When attaching valve cord to valve motor shaft, position rotor so it does not touch housing mounting screw and so that stop pin does not drag on housing as valve rotates. Tighten setscrew securely and recheck for binding and drag.

- g. When valve assembly is installed and functions without bind or drag, seat with RTV.
- 4-23. **VACUUM SENSE SWITCH ASSEMBLY.** Remove and replace the vacuum sense switch assembly as follows:
 - a. Unplug power cord from tape transport.
 - b. Unplug vacuum sense connector from control/servo PWB.
 - c. Remove screws, washers, and lockwashers securing switch assembly to top plate casting, and withdraw switch. Clean RTV sealant off mating surface of top plate casting.
 - d. Apply small bead of RTV around nozzle of new switch assembly, and replace switch in reverse order of removal procedure.
- 4-24. POWER SUPPLY ASSEMBLY. Remove and replace the power supply assembly as follows:
 - a. Unplug power cord.
 - b. Remove four screws and lockwashers securing cover to power supply chassis, and withdraw cover.

- c. Remove four screws and lockwashers securing cover to vacuum blower mounting bracket, and withdraw cover.
- d. Pull Fast-On terminals off power switch lugs. (Wires are number coded.)
- e. Remove power supply leads from terminal block and Optoisolator located on vacuum blower mounting bracket. (Wires are number coded.)
- f. Unplug power supply connector from control/servo PWB.
- g. Remove screws and lockwashers securing power supply to top plate casting, and withdraw power supply.
- h. Install replacement power supply in reverse sequence of above steps.
- i. Before applying power, verify that voltage selector PWB and correct fuse are properly installed with reference to power source voltage. (See paragraph 4-7.)
- j. Check power supply voltages in accordance with paragraphs 4-8 and 4-9.

CAPSTAN SERVO ADJUSTMENTS

- 4-25. DC OFFSET ADJUSTMENT Connect a digital voltmeter to pins I and 2 of connector P8, and adjust potentiometer R250, on the control/servo PWB (Figure 4-I), for 0 + 0.05 Vdc.
- 4-26. COARSE SPEED ADJUSTMENT. Make a coarse adjustment of speed using the following procedure:
 - a. Monitor tachometer output voltage at TP 27, located on capstan servo portion of control/servo board. (See Figure 4-1 for location of test points.)
 - b. With transport in off-line mode (ON LINE indicator not illuminated), press FWD pushbutton switch.
 - c. Adjust forward potentiometer R244 until voltage at TP 27 is approximately +2.5 Vdc at a speed of 125 ips.
 - d. Press FWD pushbutton switch to stop tape motion, then press REV pushbutton switch.
 - e. Adjust reverse potentiometer R243 until voltage at TP 27 is approximately -2.5 Vdc for a speed of 125 ips.
 - f. Press REV pushbutton switch to stop tape motion.
- 4-27. FINE SPEED ADJUSTMENT. If desired, a speed adjustment with an accuracy of 2% can be obtained with the use of the strobe disc (Figure 4-8) mounted on the capstan. (If not included on the transport, order Cipher Part No. 755005-401.) With the transport in off-line mode, press the FWD pushbutton switch. Adjust forward potentiometer R244 until the strobe disc appears to be motionless (outside lines for 60 Hz, inside lines for 50 Hz). To adjust reverse speed, use the same procedure, but press the REV pushbutton switch and adjust using reverse potentiometer R243.



920-9

Figure 4-8. Strobe Disc

4-28. ALTERNATE FORWARD AND REVERSE FINE SPEED ADJUSTMENTS. Measure and make a fine adjustment of tape speed as follows:

- a. Load known-density master skew tape on transport. Connect counter to TP 10 on dual-mode data board (Figure 4-9).
- b. With transport in off-line mode (ON LINE indicator not illuminated) press FWD pushbutton switch and adjust counter to trigger on negative-going edge of data pulse.
- c. Adjust forward speed control potentiometer R244 on capstan servo portion of control/servo board to obtain appropriate data rate of 100K bits per second (at 800 bpi, 125 ips).
- d. Press FWD pushbutton switch to stop tape motion.
- e. Press REV pushbutton switch.
- f. Adjust reverse speed control potentiometer R243 to obtain appropriate data rate in step C.
- g. Press REV pushbutton switch to stop tape motion.
- h. Readjust ramp time in accordance with paragraph 4-29.





Figure 4-9. Dual-Mode PWB Test Points, Pots, Headers, and Switches

- 4-29. RAMP ADJUSTMENT. Make this adjustment while starting and stopping the tape motion and observing the ramp in both forward and reverse modes. This can be done with the transport on line while writing blocks of data or off line by using the autocycle test mode (paragraph 5-3).
 - a. Use oscilloscope to monitor ramp tachometer test point TP 27 on control/servo board with respect to ground.
 - b. Trigger oscilloscope with run command at U-89 pin 2.
 - c. Adjust ramp potentiometer R242 to obtain ramp time of 3 ms at 125 ips. (See Figure 4-10.)



920-11

Figure 4-10. Ramp Adjustment Traces

DUAL MODE DATA BOARD INITIAL SWITCH SETTINGS

- 4-30. Refer to Tables 4-4 and 4-5 for all switch settings and functions.
- 4-31. Before making adjustments on the data PWB, set the switches initially to the following positions:
 - a. Switch I, positions I and 2: both closed.
 - b. Switch I, positions 3 and 4: see Table 4-4 for position versus transport tape speed.

TAPE SPEED	CRYSTAL FREQUENCY	SWIT	CH I
(ips)	(MHz)	Position 3	Position 4
12.5	1.280	Open	Closed
18.75	1.920	Open	Closed
25. 0	1.280	Closed	Open
37. 5	3. 840	Open	Closed
45.0	4.608	Open	Closed
75.0	3. 840	Closed	Open
90	4.608	Closed	Open
125	6.400	Closed	Open

Table 4-4. Tape Speed Crystal Frequencies and Switch I Settings

- c. Switch I, positions 5 through 7: all open; position 8: closed.
- d. Switch 2, positions I through 3: all open.
- e. Switch 2, position 4: closed.
- f. Switch 2, position 5: open.
- g. Switch 2, positions 6 and 7: see Table 4-5.
- h. Switch 3, position 1: open.
- i. Switch 3, positions 2 through 4: see Table 4-5.

CAUTION

With pushbutton SW4 closed, all tapes will be write enabled. Ensure that this switch is open when test tape or other recorded tape is on transport to prevent erasure.

NOTE

Switch 3, positions 3 and 4, must be closed for the Model 920.

POSITION FUNCTION			
FOSITION		FUNCTION	
l	2	Skew Gate	
Open	Open	Skew Gate = 12%	
Open	Closed	Skew Gate = 25%	
Closed	Open	Skew Gate = 37%	
Closed	Closed	Skew Gate = 50% (Normal Operation).	
3	4	NRZI Read Clock Frequency	
Open	Open	Not Allowed	
Open	Closed	Running Freq = 1/2 Crystal Freq	
Closed	Open	Running Freq = Crystal Freq	
Closed	Closed	Not Allowed	
5	6	Write Clock for write-all-l's in test mode.	
Open	Open	Disables clock	
Open	Closed	Provides NRZI write clock (800 fci) in test mode.	
Closed	Open	Provides PE write clock (3200 fci) in test mode.	
Closed	Closed	Not Allowed	
	7	Skew Test	
Op	en i i i i i i i i i i i i i i i i i i i	For normal operation.	
Closed		To view skew at TP 10 in skew test.	
	3	Speed Status	
Ор	en	Selects low speed status.	
Closed		Selects high speed status.	

SWITCH I

Table 4-5. Switch Settings for Testing and Options (Sheet 1 of 3)

POSIT	ION	FUNCTION	
1		Board Select	
Open		Normal operation	
Clos	sed	Forces transport select signal true for testing purposes. Overrides normal select.	
2	3	Test Mode Density Select.	
Open	Open	Normal Operation Density Select. Positions 6 and 7 determine density.	
Open	Closed	Forces PE mode. Overrides normal Operation Density Select (positions 6 and 7).	
Closed	Open	Forces NRZI mode. Overrides normal Operation Density Select (positions 6 and 7).	
Closed	Closed	Not allowed	
4	5	Threshold Detect	
Open	Open	Low threshold detect	
Open	Closed	Normal threshold	
Closed	Open	Normal threshold	
Closed	Closed	High threshold	
6	7	Normal Operation Density Select. Overridden by positions 2 and 3	
Open	Open	Low density	
Open	Closed	Control/Servo density select	
Closed	Open	High density	
Closed	Closed	Not allowed	

SWITCH 2

Table 4-5. Switch Settings for Testing and Options (Sheet 2 of 3)

POSITION		FUNICTION	
FOSITION		FUNCTION	
l		Write Reset signal routing.	
Open		This position is for Models 70X–80X and Model 100X Compliance Arm Tape Transports.	
Closed		This position is for Model 910 and 920 Tape Transports.	
2		Write Current	
Open		This position is for Models 70X–80X and Model 100X Compliance Arm Tape Transports.	
Closed		This position is for Model 910 and 920 Tape Transports.	
3	4	Voltage Regulator Operation.	
Open	Open	Allows voltage regulator operation in 70X-80X and 100X Compliance Arm Tape Transports.	
Open	Closed	Not Allowed	
Closed	Open	Not Allowed	
Closed Closed		Bypass VRI and VR2 for Model 910 and 920 transport operation.	

SWITCH 3

POSITION	FUNCTION
Open Closed	Normal Operation
tradició America de la medicación de la la	Write all I's in PE or NRZI in test mode.

SWITCH 4

WARNING

With Switch 4 closed (pressed), all tapes are write enabled and file protect is inoperative.

Table 4-5. Switch Settings for Testing and Options (Sheet 3 of 3)

READ GAIN AND SKEW ADJUSTMENTS

- NRZI. Adjust NRZI read gain as follows: 4-32.
 - Change switch settings as follows:
 - (1) Switch I, position 6: closed.
 - Switch 2, position 1: closed.
 - (3) Switch 2, position 2: closed.

NOTE

Switch settings, on the data board for test mode, override the front panel HI DEN indicator.

- See Figure 4-9 to connect oscilloscope to TP 30 and to ground. Ь.
- Press FWD pushbutton switch (indicator illuminates).
- Start writing all-I's by pressing and holding pushbutton SW-4. File d. protect is inoperative.
- Adjust gain potentiometer R203 to obtain 8-volt reading (peak-to-peak) on oscilloscope. This adjusts gain for Channel P.
- Repeat for Channels 0 through 7, using TP 31 through TP 38 and R204 through R211, respectively.

NRZI WRITE SKEW VERIFICATION. Check NRZI write skew as follows: 4-33.

- Close position 7 of switch 1. α.
- Connect oscilloscope to TP 10. Proper waveform is shown in Figure 4-11.




Figure 4-11. Skew Pulse at TP 10

4-34. PHASE-ENCODE READ GAIN VERIFICATION. Check PE read levels as follows:

- a. Make the following changes in switch positions:
 - (I) Switch I, position 5: closed.
 - (2) Switch I, position 6: open.
 - (3) Switch I, position 7: open.
 - (4) Switch 2, position 2: open.
 - (5) Switch 2, position 3: closed.

NOTE

Switch settings, on the data board for test mode, override the front panel HI DEN indicator.

- b. Press FWD switch (indicator illuminates).
- c. Start writing all I's by pressing and holding pushbutton Switch 4. File protect is inoperative.
- d. Verify 4-volt reading (peak-to-peak) at TP 30 through TP 38.

4-35. HEAD AZIMUTH ADJUSTMENT. Adjust read skew as follows:

- a. Return all switches to initial settings (paragraph 4-31).
- b. Close switch 1, position 7, and switch 2, positions 1 and 2.
- Load and tension 800-bpi master skew tape.
- d. Connect oscilloscope to TP 10 on data board (Figure 4-9) and ground.
- e. With transport in off-line, low-density mode (ON LINE and HI DEN indicators extinguished), press FWD pushbutton switch.
- f. Adjust azimuth screws (Figure 4-5) on head mounting plate so that outputs of all tracks, as monitored at TP 10, fall within 10% or less of byte-to-byte period in forward direction, and 12% in reverse direction. (See Figure 4-11.) Outer azimuth screw bears against transport mounting plate and pivots head assembly outward. Inner azimuth screw threads into transport mounting plate and pulls head assembly inward. Inner screw also serves to lock adjustment.
- 4-36. Return PWB to normal operating mode by setting all switch positions in accordance with paragraph 4-31.

CAPACITIVE TRANSDUCER ALIGNMENT

- 4–37. This alignment procedure requires the use of the diagnostic test procedure described in Section V, paragraphs 5–5 through 5–14. Align the capacitive transducers as follows:
 - a. Observe marks on facade at following points: on takeup column, at 1, $6\frac{1}{4}$ and $11\frac{1}{2}$ -inch distances from right edge of glass; on supply column, at 2, $7\frac{1}{4}$ and $12\frac{1}{2}$ -inch distances from top edge of glass.

NOTE

Diagnostic test programs 4 through 7 are used in this alignment procedure, and the diagnostic test procedure must be sequenced through test programs 1 through 3 to access 4. See paragraphs 5-5 through 5-14.

- b. During diagnostic test 4, load a full 10-1/2" reel of 1.5 mil tape approximately 10 ft past BOT marker.
- c. Increment test diagnostic to test 5 by pressing LOAD pushbutton switch once. LOAD and REWIND indicators will illuminate.

NOTE

Restrain takeup and supply reels by hand or masking tape to prevent excessive tape from entering vacuum column. Position tape loop at center of each column.

- d. Adjust zero-adjustment potentiometers R189 (supply servo) and R188 (takeup servo) on control/servo PWB (Figure 4-1) until REV and TEST lamps, respectively, change state (illuminate if previously extinguished or vice versa). Adjustments are correct at these points.
- e. Press LOAD pushbutton switch to increment test to diagnostic to test 6 (REWIND and ON LINE indicators illuminated). This test is used to adjust supply and takeup servo gains for forward tape motion.
- f. Move tape to mark at bottom of supply transducer column and to mark at right-hand side of takeup transducer column. Adjust potentiometer R190 for supply servo gain and R191 for takeup gain until TEST and REV lamps change state. Note positions of potentiometers.
- g. Press LOAD pushbutton switch to increment test diagnostic to test program 7 (LOAD, ON LINE, and REWIND indicators illuminated). This program is used to set gain adjustment potentiometers for reverse tape motion.
- h. Move tape to top mark in supply transducer column and to left-hand mark in takeup transducer column. Adjust potentiometers as in step f, noting positions of potentiometers.

- i. Readjust gain potentiometers to positions halfway between those noted in steps f and h.
- j. Check adjustments by loading a full 10- 1/2" reel of tape until an approximately equal mass of tape is obtained on both reels. Stop the tape motion and trim the offset for both the supply and take-up null points.

MECHANICAL ADJUSTMENTS

- 4-38. TAPE PATH ALIGNMENT. See Figure 4-12 and align the tape path using the following procedure:
 - a. Remove facade, head cover, and EOT/BOT cover.
 - b. Adjust takeup and supply reel hubs to proper heights, as shown in Figure 4-4.
 - c. Mount reel of tape, thread transport, and load tape. Before running tape, adjust EOT/BOT reflector parallel to and approximately 1/32-inch from tape. Adjust EOT/BOT sensor 0.150-inch from tape.
 - d. Run tape forward and reverse, and adjust reel hub height as required to center tape on reels.
 - e. Run tape forward for approximately half of reel. Run tape in reverse, and observe position of tape on capstan sleeve.
 - f. Stop tape and adjust height of capstan sleeve in accordance with paragraph 4-18 so that tape is centered on sleeve when running in reverse direction.
 - g. Run tape alternately forward and reverse, and observe tape position on capstan sleeve. Tape position should not shift when direction of tape travel is changed.
 - h. If tape shift is observed, capstan motor tilt must be adjusted. If tape moves away from top plate when running forward, capstan sleeve must be tilted away from head and guides. To tilt sleeve slightly, loosen mounting screw farthest from head and guides, and install mylar shim(s) between motor and top plate as shown in Figure 4-13. Adjustment is correct when no shift is visible when tape direction is changed and all screws are securely tightened.
 - i. If tape moves toward top plate when running forward, capstan sleeve must be tilted toward head and guides. Slightly loosen two motor mounting screws closest to head and install mylar shim(s) between motor and top plate, centering shims 180, from screw indicated in Figure 4-13. Adjustment is corrected when no shift is visible when tape direction is changed and all screws are securely tightened.





Figure 4-12. Tape Path Alignment




920-14

Figure 4-13. Motor Tilt Procedure

- j. Run tape forward and reverse to verify that tape is centered on reels and on capstan sleeve and that it does not shift or curl on any of tape guides or rollers.
- k. Check read gain levels using the procedure in paragraphs 4-32 and 4-34.
- 1. Adjust head azimuth as outlined in paragraph 4-35.
- m. Reinstall facade, head cover, and EOT/BOT cover.
- 4-39. REEL HUB ADJUSTMENT. See Figure 4-14 and adjust the reel hub as follows:
 - a. Remove tape reel and leave lock open.
 - b. If lock has free play in open position, loosen locknut on adjustment setscrew. Turn adjustment setscrew into spacer until free play is removed, and tighten down locknut.
 - c. Close lock and note whether face of lock is parallel to top of cap. If not, open lock and turn buttonhead screw in or out as necessary to hold lock parallel to top of cap in closed position.
 - d. Place reel on hub, close lock, and check reel for tightness. If reel slips on hub, open lock and remove reel.
 - e. Loosen hex locknut on adjustment setscrew, turn adjustment setscrew slightly into spacer (depending upon looseness of reel), and retighten locknut.
 - f. Perform steps c and d.
 - g. Perform steps e, c, and d as necessary until reel does not slip.

NOTE

Hub compression ring contains oily preservative which tends to ooze out through pores and make surface oily. Ring should be cleaned periodically with isopropyl alcohol to prevent tape reel from slipping.




920-15

Figure 4-14. Reel Hub Assembly

REPLACEMENT OF ELECTRONIC ASSEMBLIES

- 4-40. These instructions provide a logical procedure for replacing assemblies.
- 4-41. CONTROL/SERVO BOARD. Replace the control/servo board as follows:
 - a. Disconnect all cables from board.
 - b. Remove screws from corners of mounting bracket as shown in Figure 4-15.
 - c. Slide board out of top and bottom mounting brackets.
 - d. Slide in replacement board and screw bracket back together at corners.
 - e. Reconnect all cables.
 - f. Turn on power and check power supply voltages.
 - g. Adjust the capstan servo, ramp time, and capacitive transducer in accordance with paragraphs 4-25 through 4-29 and 4-37.
- 4-42. DUAL MODE DATA PWB. Replace the data PWB as follows:
 - Remove two screws securing PWB to unhinged standoffs.
 - b. Swing PWB out on standoff hinges and carefully remove head connectors and power/signal cable.



920-16

Figure 4-15. Control/Servo Board Removal

- c. Support PWB and remove two screws securing board to hinged standoffs.
- d. Replace PWB in reverse sequence of removal.
- e. Adjust new data PWB in accordance with paragraphs 4-30 through 4-36.
- 4-43. FILE PROTECT SENSOR. The complete file protect sensor is built and tested as an assembly and must be replaced as such. Remove and replace as follows:
 - a. Unplug electrical connector from control/servo PWB.
 - b. Remove two screws securing sensor brackets and one screw securing cable clamp. Carefully pull cable and connector through hole provided in top plate casting.
 - c. Install replacement sensor in reverse order of removal. Adjust sensor-to-file protect ring distance to 0.1 inch. No electrical adjustments are required.
- 4-44. VACUUM FLOOR/TRANSDUCER ASSEMBLY. The Model 920 transport has two vacuum floor assemblies (supply and takeup) to which one transducer assembly is bonded. Determine which vacuum floor assembly is at fault, and replace the complete assembly as follows:

NOTE

Vacuum floor assemblies consisting of a vacuum column floor and a transducer assembly can be returned to factory for repair at a nominal charge.

- a. Determine which assembly is at fault. Unplug corresponding connector body from control/servo PWB. Remove cable from connector body using Molex Tool Part No. HT-2038.
- b. Loosen three press-lock fasteners securing defective vacuum floor/transducer assembly.
- c. Remove screws securing four vacuum column walls and vacuum floor assembly to top plate. Save any shims under wall or vacuum floor assembly.
- d. Lift floor/transducer assembly carefully from top plate. (When removing bottom floor/transducer assembly, take care not to damage capstan sleeve.) Disconnect silicone tubing from tee assembly in vacuum column. Feed transducer cable through rubber grommet, and remove complete assembly.
- e. Install replacement floor/transducer assembly in reverse order of removal. Push silicone tubing back over tee assembly, checking that all other tubing connections in vacuum column have not been disturbed. Replace any shims removed in step c or d.
- f. Before tightening screws that secure vacuum column walls, ensure that capstan sleeve does not rub on wall (in bottom vacuum column) closest to it and that roller guide does not rub against wall closest to it inside vacuum column.

- g. Insert cable contacts into connector housing, as shown in Top Assembly Drawing No. 155000-998 (Section VII), and plug connector into corresponding control/servo PWB.
- h. Adjust the capacitive transducer as specified in paragraph 4-37.

REMOVAL AND REPLACEMENT OF ELECTRONIC PARTS AND COMPONENTS

4-45. Select replacement parts and components from the parts list in the engineering drawing package provided with the equipment. Observe the following special procedures for removing and replacing parts on printed circuit boards:

CAUTION

To prevent excessive heat from damaging printed circuit boards and components, especially semiconductors, use a soldering iron rated at not more than 40 watts or 600 degrees F, and do not heat solder for more than 10 seconds. When soldering, always use heat sink (alligator clip, long-nose pliers, etc.).

- a. Use only 60-40 tin-lead solder with noncorrosive, nonconducting flux. Use alcohol or commercial flux-removing solvent to remove flux residue.
- b. After component has been removed from board, clean all solder from connections (plated-through holes) with commercial solder sucker (Soldapullt desoldering tool, Edsyn Co., or equivalent).

NOTE

Do not alter wiring or layout.

- 4-46. MULTIPLE-LEAD COMPONENTS. Follow instructions in paragraph 4-45 for removal of a defective two- or three-lead component. Bend the leads on the replacement component to the proper shape and install. Heat may be applied to either side of the printed circuit board, as necessary.
- 4-47. MULTIPLE PIN COMPONENTS. Remove and replace multiple-pin components, including integrated circuits as follows:

CAUTION

Exercise great care in the removal of multiplepin components from printed circuit boards to avoid damage to boards.

- a. Remove defective component by carefully cutting each lead close to component, using jeweler-type diagonal cutter.
- b. Remove lead ends and solder from holes in board in accordance with instructions in paragraph 4-45.
- c. Straighten leads in replacement component for insertion in board and install.

PROGRAMMING WRITE DESKEW PROM

4-48. Inscribed on the tape head of the Cipher Model 920 transport is an eight-digit code which describes the deskew pattern to be programmed into the write deskew PROM (U90, Drawing No. 154040-009) to implement a write deskew pattern on the dual mode data PWB for that head. The position of each digit in the code corresponds to a head channel number, starting with channel 7 on the left, to channel 0 on the right. The one exception is that position 2 of the code corresponds to channel P (parity). Channel 2 is the reference channel. The numerical value of each digit of the code corresponds to the address of its channel for which a 0 must be programmed into the PROM.

4-49. Tables 4-6, 4-7, and 4-8 illustrate bit maps of programmed PROMs required for three different hypothetical head codings. Column heading numbers correspond to head channel numbers (except for 2). Each I in the tables represents a logic high, and each 0 represents a logic low. Note that there is one and only one 0 in each bit column and that there are no 0's from address 10 to address IF. There may be none, one, or more than one 0 in each of addresses (rows) 00 through 0F.

- 4-50. PROCEDURE. To program a PROM with a specific code, proceed as follows:
 - a. Obtain unprogrammed PROM, Cipher Part No. 203565-123 (828123 or equivalent).
 - b. Note code on tape head with which PROM is to be used.
 - c. Program PROM in accordance with manufacturer's specifications to obtain logic lows at address/bit locations indicated by code and logic highs at all other locations.

NOTE

Most PROM distributors are equipped to program PROMs.

BIT L 7 6 5	OCATI	0N 0
00		

BIT LOCATION			
76543210			
00			
011111111			
02			
03			
04			
05			
06			
07 0 0 0 0 0 0 0 0			
08			
09			
0A			
0B			
0C			
0D			
0E			
0F			
10 1 1 1 1 1 1 1			
11 1 1 1 1 1 1 1 1			
12			
13			
14 1 1 1 1			
15			
16			
17			
18			
19			
IA			
IB I I I I I I I			
ID I I I I I I I			
IE			
IF			

Table 4-6. Bit Map, Code 23456789

Table 4-7. Bit Map, Code 77777777

Table 4-8. Bit Map, Code 6789A987

VOLUME I

SECTION V

TESTING AND TROUBLESHOOTING

TESTING

- 5-1. The Model 920 transport incorporates three separate types of internal testing facilities called self-test, test mode operation, and diagnostic mode operation. These facilities are accessed with control panel pushbuttons to provide detection of certain fault conditions and to provide alignment and test aids for preventive maintenance.
- 5-2. SELF TEST. During power-up operation, all indicator lights on the control panel are illuminated for approximately one second. If all indicators are off except LOAD following this period of time, no defect is indicated. If all indicators remain illuminated, a defect in the PROM, timer, or microprocessor is indicated. If all indicators but LOAD remain illuminated, a defective RAM is indicated.
- 5-3. TEST MODE OPERATION. Use off-line operation of the Model 920 in the test mode to adjust start and stop ramp times and to verify proper operation of the servos. To access the test mode, power up the transport and load a reel of tape.
- 5-4. Refer to Figure 3-1, which illustrates the controls and indicators of the Model 920, and use the following switch sequences to activate the various functions of the test mode.
 - a. Press TEST and FWD pushbutton switches momentarily. Transport performs alternate forward and stop operations to permit adjustment of start/stop ramp times. (See paragraph 4-29 for adjustment procedure.) To terminate test, press FWD pushbutton switch momentarily. FWD indicator turns off and transport stops.
 - b. Press REV pushbutton switch momentarily. Transport performs alternate reverse and stop functions to check start/stop ramp times. (See paragraph 4-29.) Press REV pushbutton switch momentarily to terminate.
 - c. Press FWD and REV pushbutton switches momentarily while in TEST mode. Tape moves forward two unit times and reverse one unit time, continuing until EOT. Transport will then perform rewind operation and continue forward and reverse operations. Purpose of this test is to check operation of servos. Reel hubs and capstan should operate simultaneously, starting, stopping, and turning in same direction.

- 5-5. DIAGNOSTIC MODE. The diagnostic mode is designed to aid troubleshooting by helping to locate and isolate fault conditions. This mode provides for verification of proper servo and sensor operation, for diagnostic functions, and for transducer alignment.
- 5-6. The upper three indicators on the control panel indicate in binary notation the number of the test being performed (refer to Figure 3-1). The value of LOAD is 1, ON LINE is 2, and REWIND is 4. For example, if ON LINE is the only one on, the test is number 2; if all are on, it is number 7. The remaining indicators are used to confirm proper operation of most of the major circuits in the transport.
- 5-7. To access the diagnostic mode, switch transport to ON and unload any tape. Press pushbutton switches TEST, FWD, and WRT EN simultaneously and hold; then press and hold in the LOAD pushbutton switch for 2 to 3 seconds. The LOAD indicator illuminates, after a slight delay, when test 1 is accessed.
- 5-8. Test I. This test enables all three servos, sequencing the reel hubs and capstan clockwise and counterclockwise and testing about 85% of the servo circuitry. Any polarity reversal will be detected, since the reel for a servo with reversed polarity will rotate in the opposite direction of the capstan motor.
- 5-9. To terminate this test, press the LOAD pushbutton switch momentarily. The LOAD indicator turns off and ON LINE illuminates, indicating that Test 2 is accessed.
- 5-10. Test 2. Only the supply servo is activated in this test. Its purpose is to check operation of the write enable, file-protect, EOT, and BOT sensors and their electronics. The supply reel rotates in one direction. The displays that indicate the proper function or malfunction of BOT, EOT, quadrature phase 0, and phase I are listed in Table 5-1.

FUNCTION	DISPLAY
The BOT sensor detects reflected light and BOT electronics are operating.	TEST indicator illuminates
No reflected BOT light (tape in path) or inoperative electronics.	TEST indicator off
The EOT sensor detects reflected light and EOT electronics are operating.	REVERSE indicator illuminates
No reflected EOT light (tape in path) or inoperative electronics.	REVERSE indicator off
Quadrature phase 0 sensor detects reflected light and electronics are operating.	HI DENSITY indicator off
Phase 0 sensor not detecting reflected light.	HI DENSITY indicator illuminates
Rotating hub causes above two functions to alternate.	HI DENSITY indicator flashes
Quadrature phase I sensor detects reflected light and electronics are operating.	FORWARD indicator off
Phase I sensor not detecting reflected light.	FORWARD indicator illuminates
Rotating hub causes above two functions to alternate.	FORWARD indicator flashes
An illegal phase change has occurred or an illegal phase relationship exists.	WRITE ENABLE indicator illuminates

Table 5-1. Photo-sensor Functions

- 5-11. To terminate Test 2, press the LOAD pushbutton switch momentarily. LOAD and ON LINE indicators illuminate, indicating that Test 3 is accessed.
- 5-12. Test 3. This test is for diagnostic and repair purposes only. The rewind copstan circuitry is activated, and the capstan ramps up in a clockwise (rewind) direction, stops, and repeats this procedure until the test is terminated. Momentary actuation of the LOAD pushbutton switch at this point illuminates the REWIND indicator (LOAD and ON LINE off), accessing Test 4.
- 5-13. Tests 4, 5, 6, and 7. At test 4, all servos are disabled to permit loading of tape for Tests 5 through 7. Mount a reel of tape and momentarily press the LOAD pushbutton switch to load the transport and access Test 5. The LOAD and REWIND indicators illuminate for Test 5.
- 5-14. Refer to paragraph 4-37 for the capacitive transducer alignment procedure performed in Tests 5, 6, and 7. Press the LOAD switch to sequence these tests and, to exit the diagnostic mode, hold down the OFF LINE switch and press the LOAD switch.

TROUBLESHOOTING

- 5-15. Before performing any troubleshooting operation, be familiar with the theory of operation of the transport and any associated equipment. Check carefully to ensure that all equipment is connected properly and that all associated equipment is in good operating condition. Be familiar with operating instructions and follow them carefully while performing the troubleshooting procedure.
- 5-16. PROCEDURE. While it is recognized that each individual malfunction requires its own specific troubleshooting procedure, the following steps serve as general guidelines.
 - a. As a first step, inspect entire unit visually for any signs of damaged or overheated components. Also, listen for unusual noises, while transport is operating, which may indicate mechanical malfunctions.
 - b. When a defective component is located, identify it by referring to the engineering drawing package provided with the equipment for part number and/or value.
 - c. If replacement part is available, substitute it for suspected defective part.

NOTE

If correction of any malfunction involves major realignment of transport, it is recommended that unit be returned to Cipher Data Products for factory repair and adjustment.

5-17. Table 5-2 lists possible defects associated with the operation of a tape transport and describes probable causes and remedies.

TROUBLE	PROBABLE CAUSE	REMEDY
Reel flanges scrape tape	Reels improperly mounted	Reinstall reel evenly (See Section III)
BOT and EOT markers not sensed	Dirt covering reflec- tive strip or sensor	Clean sensor or reflective strip.
	EOT/BOT sensor or logic defective	Replace EOT/BOT assembly; repair logic
Tape fails to pull properly through machine or spills	lmproper tape threading	Rethread tape (See Section III)
Excessive data dropout	Dirt on head or damaged tape	Clean head (Section IV) and/or install new certified computer tape
Recorder will not function at all	Defective fuse	Replace fuse
POWER switch light does not illuminate	No primary power	Check for primary power
	Defective indicator lamp	Replace control/indicator
Machine does not accept commands	Improper interface	Check interface with DTL logic and correct as necessary.
	More than one command true simultaneously	Enables only desired command; hold other inputs high
Tape continues to advance during Load mode	No BOT marker on tape	Affix marker to tape approximately 12 ft from physical beginning of tape; place marker near reference edge on backing side of tape
Tape tensioned but does not advance when capstan turns	Tape not threaded over capstan properly	Rethread tape (See Section III)
Tape tensioned but slips	Dirty capstan	Clean capstan in accordance with Section IV

Table 5-2. System Troubleshooting (Sheet 1 of 4)

TROUBLE	PROBABLE CAUSE	REMEDY
Tape moves during a stop condition	Defective capstan	Replace capstan assembly and realign servo
	Motor voltage not zero	Check capstan servo and adjust for zero offset; repair if adjustment does not correct.
Tape not tensioned or tape is spilled when Ready mode is set	Improper tape threading	See Section III
	Reel servo or motor malfunctioning	Replace motor or repair reel servo
Computer does not read tapes correctly	Data format incorrect	Use correct format
	Record length exceeds computer memory capability	Use correct record length
Transport does not move tape in response to FORWARD or REVERSE commands	Interface cable fault or receiver fault	Check levels at outputs and inputs of receivers on servo board; replace or repair cable or repair servo board
1	Transport not in Ready Mode	Bring tape to load point (Section III)
	Fault in ramp generator or capstan servo-amplifier	Repair servo board

Table 5-2. System Troubleshooting (Sheet 2 of 4)

TROUBLE	PROBABLE CAUSE	REMEDY
Transport responds to remote FORWARD command, but tape is not written	Write current is not enabled	Check presence of write enable ring on supply reel; WRT EN indicator should be illuminated. Check for +5V at write current transistor on write board while writing; if not present, check for +5V, at power connector. Also check for +5V on servo board.
	WRITE ENABLE signal not correct	Check receiver on control/power board; check for RUN signal on read/write board; repair read/write or control/power board if faulty
	Write data or write data strobe not received correctly from interface	Check presence of correct levels on write portion of read/write board; repair write portion of read/write board or interface cable if faulty
	Heads not plugged in correctly	Check J21 on read/write board
Data incorrectly written	Incorrect data format	Use correct format
	Fault on one track due to failure in write circuits	Check receiver and write amplifier on write portion of read/write board; repair if faulty
	Intermittent +5V, RUN or WARS	Examine signals and repair servo or read/write board, as required
	Write deskew circuit faulty	Check skew adjustments (See Section IV)
	Head and guides need cleaning	Clean heads and guides
	Tape cleaner needs emptying	Remove tape cleaner and clean

Table 5-2. System Troubleshooting (Sheeet 3 of 4)

TROUBLE	PROBABLE CAUSE	REMEDY
Tape cannot be read	Interface cable or transmitter faulty	Replace or repair interface cable or transmitter on read/write board
	Head not plugged in	Check J22 on read/write board
	Read skew out of adjustment	Readjust in accordance with Section IV.
·	Head and guides need cleaning	Clean head and guides
	Tape cleaner needs emptying	Remove tape cleaner and clean
	Read amplifier gains incorrectly adjusted	Check and adjust amplifier gains
	Read data storage register faulty	Check read gate on read/write board; check that duration of positive section of waveform is one-half bit time
	Other component fault in read channe!	Check test point data; repair read/write board

Table 5-2. System Troubleshooting (Sheet 4 of 4)

			901 POWER SUPPLY ASSY		06-11-82 (FRI	
QTY	GIVEN IS NUM	IBER O	F PARTS OR LENGTH OF MATERI	AL IN FEET •		47 LINES OF
LTEM	PART #	QTY	DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE END-DATE
• • • •	* * * * * * * * * *	• • •	* * * * * * * * * * * * * * * * * * * *	***************		444444
1	151017-001	1	FWB ASSY-FOWER SUFFLY	CIFHER DATA PROD		******
2	799008-21 0	1	TRANSFORMER-POWER	SEE DRAWING		
3	754035-301	1	BASE-FOHER SUPPLY	CIPHER DATA FROD		
4	799016-801	i	FILTER-EMI,5AMP	RAYTHEON	FL1	08-01-82 Lx47
5	205198-01 0	· 1	RECEPTACLE-POWER	5K1R CORCOM INC		
6	202004-100	.1	RECTIFIER BRIDGE	6J1 MOTOROLA SEMI.	CR1	
7	210229-050	1	CLAMP, CABLE-3/8 BLACK	MDA-980-2 NOT ON FILE		•
8	210288-000	+4	GROMMET STRIP	8944 NOT ON FILE		-
9	210408008	•7	TUBING-HEAT SHRINK, 1/8,ELK	MS21266-2N ICO RALLY	•	
10	210408-012	•5	TUBING-HEAT SHRINK, 3/16,ELK	HIX-1/8 ICO RALLY		
11.	210132	1	GROMMET	H1X-3/16 SMITH, HERMAN H.		
12	210229-523	8	TY-RAP-1/16 TO 5/8	2146 ICO RALLY		
13				WRN 3 1/2		
11	731006-800	1	LABEL-ASSY	CIPHER DATA FROD	-	
15				and the side of th		
16	210555-025	5	TERMINAL RING #6 SM PAT	HOLLINGSWORTH TERM. CO.		
17	210555-03 3	4	TERMINAL, SLIF-ON, 250 TAB	R1881S HOLLINGSWORTH TERM. CO.		
18	208400-121	3.1	WIRE-STRD, 16AMG, IR, PVC	S05305F-T1 ALPHA WIRE	·	
19	208405-112	•7	WIRE-STED, 18ANG, IRPVC, BLK	7134-1 CSA/UL JUDD WIRE HH0402		

PAGE 1 OF 3

FARTS	LIST 154	017-9	01 FOWER SUPFLY ASSY	, REV AD ECO# 12240	06-11-82 (FRI	NTED: 06-11 47 LI	
OTY CI	TUEN TS NUME	ER OF	FARTS OR LENGTH OF MATERIAL	L IN FEET			
TTEM	CIPHER	QTY	DESCRIPTION 1	MFG-NAME	REF-DES	ST-DATE	END-DATE
	PART #		DESCRIFTION 2	MFG-PART#			
* * * *	••••••	• • •	*****************				
20	208405-111	.7	WIRE, STRD, 18AWG, IRPVC, WHT	JUDD WIRE HH0402			
21	200405-014	1.0	WIRE-STRD, 18GA, IR FVC GRN	ALFHA WIRE 7155-4		•	
22	208400-111	11.6	WIRE-STRD, 16AMG, IRPVC, WHT	JUDD WIRE HH0405	•		
23	208400-112	2.7	WIRE-STRD, 16AHG, IRPVC, ELK	JUDD WIRE HH0405	•		
24	208300-001	2	WIRE-STRD,14ANG,PVC,UL	ALPHA WIRE 3079-1 CSA/UL	•		
25	209979-000	11	MARKER, WIRE - 1-50	ANY ACCEPTABLE SOURCE		•	
26	754053-301	1	LABEL-RECTIFIER ID	CIPHER DATA PROD			
27	213274-604	2	SCREW-PAN HD FHIL 6-32 X 1/4, CAD, ZINC	ANY ACCEPTABLE SOURCE			
28 29	213271-606	5	SCREN-PAN HEAD PHIL, 6-32 X 3/8, CAD BLK, OR ZIN	ANY ACCEPTABLE SOURCE		•	
30	213271-608	1	SCREW-PAN HD FHIL 6-32 X 1/2, CAD, ELK, ZINC	ANY ACCEPTABLE SOURCE			S
31	213092-612	1	SCREW-SKT HD CAP, 6-32 X 3/4, BLK ONLY	ANY ACCEPTABLE SOURCE			
32							
33							
. 34	213151-108	4	SCREW-FLAT HD FHIL, 100 10-32 X 1/2 CAD, ELK, ZINC	ANY ACCEPTABLE SOURCE			
35	207602-011	. 4	WASHER, SPLIT LOCK #6	ANY ACCEPTABLE SOURCE WASHER #6 CAD.			
36	297608-021	. 1	WASHER, FLAT, SMALL OD #6	ANY ACCEPTABLE SOURCE WASHER #6 CAD.			
37	207605-021	l 1	WASHER FLAT #6	ANY ACCEPTABLE SOURCE WASHER #6 CAD.			
38 37		L 1	HASHERYSPLIT LOCK #10	ANY ACCEPTABLE SOURCE WASHER #10 CAD.			

QTY (NUM EI NUM	BER OF	FARTS OR LENGTH OF MATERI	AL IN FEET		NTED: 06-11-82) PAGE 47 LINES
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME	REF-DES	ST-DATE END-DATE
• • • •	,,,,,,	• • •		**************************************	***********	
40	207104-021	4	WASHER, FLAT, #10	ANY ACCEPTABLE SOURCE		*******
41	213898-610	2	SFEED NUT-6-32,F	WASHER #10 CAD. NOT ON FILE		
42	207607-051	2	NUT, HEX #6 6-32	C8094-632 ANY ACCEPTABLE SOURCE	en e	
43	207101-081	4	NUT, HEX, RADIO PAT. #10 10-32	NUT #6 CAD.		•
14	210555-049	1	TERMINAL-RING, 16-14AWG, #8			·
45	*****	****	*************************	F1902S **********************	KXXXXXXXXXXXXXXXXX	•
46						
47	799005-101	1	FILTER-EM1,5 AMP,K SERIES	CORCOM INC 5K1	FL1	L *4 07-31-82

PARTS	LIST 154	1010-80	11 REEL HUB ASSY-SUPPLY	REV G ECO# 11919'	12-07-81 (F	*RINTED: 12-09 25 LI	-81) PAGE 1 NES OF 2
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFGNAME MFGPART#	KEF-DES	51-DHIE	ERLYINTIE.
	******	+ + +.			• • • • • • • • • • • • • • • • • •	• • • • • • • • • • • • • • • • • • • •	* * * * * * * *
1	754009-901	1	REEL HUB MODIFICATION	CIPHER DATA PROD			
2	731910-200	1	CAP-REEL HUB	CIPHER DATA PROD			
3	731922-500	1	LOCK-REEL HUB MACHINING	CIPHER DATA PROD			
4	731922-202	1	REEL HUB-SPACER, ADJ, MOD	CIPHER DATA PROD			
5	710010-400	1	COMPRESSION RING REEL HUB	CIPHER DATA PROD			
6	154002-601	1	RING ASSY-FILE PROTECT	CIPHER DATA PROD			
7	731013-400	2	PIN-REEL HUB	CIPHER DATA PROD			
8	754003-501	3	CONICAL CPRSN SPRING	CIPHER DATA PROO			
9	213062-604	1	SCREW-BTN HD SKT 6-32 X 1/4 BLK O	ANY ACCEPTABLE SOURCE			
10	213622-608	1	SCREW-SKT SET KNURL CUP PT,6-32 X 1/2,BLK ONLY	ANY ACCEPTABLE SOURCE			
11	207604-081	1	NUT-HEX RADIO PATTERN 6-32	ANY ACCEPTABLE SOURCE NUT #6 CAD.			
12	210029-003	3	NUT-HEX,LIGHT,THIN #4	ESNA 22NTM-40			
13	209990-07 <i>6</i>	AR	RETAINING COMPOUND-FAST	LOCTITE 601			
14	213092-612	2 2	SCREW-SKT HD CAP, 6-32 X 3/4,BLK ONLY	ANY ACCEPTABLE SOURCE			
15	213352-604	2	SCREW-SKT SET CUP PT. 6-32 X 1/4, BLK ONLY	ANY ACCEPTABLE SOURCE			
16	213351-410) 3	SCREW-SKT, SET, CUP, PT, CAD, BLK, ZINK, 40-40X, 5/8	ANY ACCEPTABLE SOURCE			
17	209999-031	. AR	STP OIL TREATMENT	209999-031			
	209990-075		ADHESIVE-THREAD LOCKING, AEROBIC	VC 3			
19	* REF DWG	600103	3-100 REEL HUB ASSY-PROCEDUR	RE			

*_k (

PAR		010-80			(rEV	G	ECO#	11919	12-07-81	, (FRI)	TED: 12-0 25 LI		SE
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2		MFG-	MAM-	Ē	* * * * * *	REF-DE		ST-DATE	END-DATE	
* * * *	* * * * * * * * * * * *	* * *		******	* * * * * * * * * * * *	* * *	• • • • •	• • • • •	• • • • • • • • • • • • • • • • • • • •		* * * * * * * *	* * * * * * * *	
20	- 22 ARE BI	LANK.											
23	210408-006	.2 1	TUBING-HEAT SHRIN	IK•BLACK	ICO RALLY								
24					H1X-3/32								
25	*****	****	*******	*****	*****	кжжж	кжжжж	****	**** ********	K XXXXXXX			

PARTS	LIST 154	1017-0	01 PWB ASSY-POWER SUPPLY	REV G ECO# 10231	08-17-81	(PRINTED: 08-1 21 L	8-81) PAGE INES ØF2
ITEM	CIPHER PART #	aty	DESCRIPTION 1 DESCRIPTION 2	MFGNAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	• • • • • • • • •	• • •	*******************	***************************************	* * * * * * * * * * * * * * * * * * * *		
	754017-101	1	PWB-POWER SUPPLY	DIBBLE ELECTRONICS TYPE 1 OR 2	,		
2							
3	205066-500	1	CONNECTOR-6 POSN	MOLEX,INC. 03-09-1063			
4	205014	1	TERM-MALE,18-22AWG,.093 DIA, REEL	MOLEX,INC. 02-09-2116			
5	201174-158	3	CAP-ELECT, 15800UF, 75V	SEE DRAWING 91S75JF1582	C1,2,3		
6	200123-300	1	RES-WW,3K,3.75W,5%	DALE ELEC. INC. CW-2B .1-9K	R1		
7	205015	5	TERM-FEM 18-22AWG.093DIA REEL	MOLEX,INC. 02-09-1116			
8	210229-523	8	TY-RAP-1/16 TO 5/8	ICO RALLY WRN 3 1/2			
9	210555-033	2	TERMINAL, SLIP-ON, 250 TAB	HOLLINGSWORTH TERM. CO. S05305F-T1			
10	208405-111	16.7	WIRE,STRD,18AWG,IRPVC,WHT	JUDD WIRE HH0402			
11	208400-111	.10	WIRE-STRD,16AWG,IRPVC,WHT	JUDD WIRE HH0405			
12	209999-000	2	MARKER, WIRE- 1-50	ANY ACCEPTABLE SOURCE VMM-0-49			
13 14							
15	210032-240	4	STDOFF-1/4 RND,1/2, 6-32,SWAGE	KEYSTONE 1604-3			
16	213271-106	6	SCREW-PAN HD PHIL, 10-32 X 3/8, CAD, ELK, ZINC	ANY ACCEPTABLE SOURCE			
ALT	213271-108		SCREW-PAN HEAD PHIL, 10-32 X 1/2, CAD, ELK, ZINC	ANY ACCEPTABLE SOURCE			
17							

PARTS	LIST 154	401 <i>7</i> -001	L PWB ASSY-POWER (SUPPLY	REV G ECO# 10231	08-17-81 . (PRIN	TED: 08-18 21 LI	22
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	• • • • • •	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
* * * *	********	* • • •	• • • • • • • • • • • • • • • • • • • •	• • • • •	***************************************	******	• • • • • • •	• • • • • • •
19	207102-011	6 1	AASHER,SPLIT LOCK #:	10	ANY ACCEPTABLE SOURCE WASHER #10 CAD.			
20	207108-021	6. 1	HASHER, FLAT, SMALL (OD #10	ANY ACCEPTABLE SOURCE WASHER #10 CAD.			
21	4							

.

PART	S LIST 154	1005-0	01 PWB ASSY-SWITCHES	REV S ECO# 12246	01-22-82 (FRIM	TED: 01-25	
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	• • • • • • • • •	• • •	• • • • • • • • • • • • • • • • • • • •	**********************		• • • • • • •	******
1	754005-10 1	1	PWB-SWITCHES	CIPHER DATA PROD			
2 3	154076-101	1	CABLE ASSY-SWITCHES	CIPHER DATA PROD			
4	208415-112	.5	WIRE-STRD-22AWG,IRPVC,BLK	JUDD WIRE HH0314			:
5			•				
6							
7							
8				•			
9							
10			·	•			
10							
	210806-500		SWITCH-PUSH BUTTON, MOM	ROOD SHITCH RS5035	S1-8		
12	203052-259	1	IC-MULTIPLEXER/3 ST OUT	TEXAS INSTRUMENTS SN74259	U1		
13	203052-251	1	IC-8BIT ADDRESSABLE LATCH		U2		
14	205249	1	RESISTOR NETWORK-10K, 14 PIN *	BECKMAN INSTRUMENTS, INC. 899-1-R10K	U3		
15 16	212000-101	8	DIODE-LIGHT EMITTING RED	HEWLET PACKARD 5082-4670	CR1-8		
17	200072-220	8	RES FC 220 OHM 1/4W 5%	NOT ON FILE RCR07G221JM	R1-8		
18	201149-470	1	CAP FC .047UF 50V 5%	EL PAC C5A473J	C1		
19	201105-010	1	CAP,CER,DISC,.01UF,500V	SPRAGUE 5	C2		
20	3 10032-100	4	STDOFF-1/4 RND,1/8, 4-40,SWAGE	AMATOM CECTRONIC HDW 95318-A-40			

PARTS	5 LIST 154	7005-(REV S ECO# 12246	11 11001	31 L3	
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
* * * *		* * *	* ********************	******************	**************	******	* * * * * * * *
21	354005-301	REF	SCHEM-FWB, SWITCHES	CIPHER DATA PROD			
22	210229-300	1	CABLE, CLAMP 1/4 WHT	ANY ACCEPTABLE SOURCE		04- 01-82	L*31
23				www i			
24	213271-607	1	SCREW-PAN HD PHIL, 6-32 X 7/16,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE			
25	207605-021	1	WASHER, FLAT #6	ANY ACCEPTABLE SOURCE WASHER #6 CAD.			
26	207602-011	1	WASHER, SPLIT LOCK #6	ANY ACCEPTABLE SOURCE WASHER #6 CAD.			
27	207607-051	1	NUT, HEX #6 6-32	ANY ACCEPTABLE SOURCE NUT #6 CAD.			
28 29				HUI TO CHU!			
30	*****	****	******	**********	*********		
31	210229-200	1	CLAMP, CABLE-3/16 WHITE	NOT ON FILE 3303		L*22	03-31-82

PARTS	LIST 154	040-0	08 PWB ASSY-DATA DUAL, 9TK,RAW,125IPS	REV A	09-27-78 (PRI)	TED: 07-31 5 LTN	ES OF I
TTEN	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	*******	• • •		*****************	***************	* * * * * * * *	+ > + + + + + >
1.	154040-009	1	PWB ASSY-DATA DUAL, 9TK,RAW (NO SPEED KIT)	CIPHER DATA PROD			
2	154040-608	1	SPEED KIT-125 IPS	CIPHER DATA PROD			
3				·			
4	454040-000	REF	DASH NO INDEX/PWB ASSY-	CIPHER DATA PROD			
5	354040-300	REF	DATA DUAL SCHEMATIC-DATA, DUAL MODE	CIPHER DATA PROD	•		

ITEM CIPHER QTY DESCRIPTION 1 MFC-NAME	QTY	GIVEN IS NUM	4040-(BER OF	009 PWB ASSY-BATA DUAL, 9TK,RAW (NO SPEED KIT PARTS OR LENGTH OF MATERI	REV AJ ECO# 1397; ') 'AL IN FEET	7 08-20-82 (PR	INTED: 08-2(140 I	
1 754040-101 1 PWE-DATA,DUAL MODE TIPE 1 OR 2 2 731511-201 1 STIFFENER LONG READ/WRITE CIPHER DATA PROD 3 731510-400 1 BAR STIFFENER CIPHER DATA PROD 4 731501-300 4 RETAINER-P/C CONNECTOR CIPHER DATA PROD 5 735000-402 2 SPACER CIPHER DATA PROD 6 205026 37 TEST POINT .058 DIA PIN AMP INC. 60802-2 MOLEX,INC. 920 MOLEX,INC. 920-2:134 MOLEY,INC. 920-2:134 MOLEY	,	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME			END-DATE
1 754040-101 1 PWB-DATA,DUAL MODE TYPE 1 OR 2 731511-201 1 STIFFENER-LONG READ/WRITE CIPHER DATA PROD 731510-400 1 BAR STIFFENER CIPHER DATA PROD 731501-300 4 RETAINER-P/C CONNECTOR CIPHER DATA PROD 735000-402 2 SPACER CIPHER DATA PROD 7 205086 1 CONNECTOR-12 POSN MOLEX,INC. 03-09-2121 MOLEX,INC. 02-09-2134 MOT ON FILE 159-1050P WINCHESTER ELECTRONICS SE 2 PD4J WINCHESTER ELECTRONICS SE 2 PD4J MP INC. 11015-003 1 SWITCH-DIP,7POS,SEALED AMP INC. S1 2-435688-0 AMP INC. S2 2-43568-0 AMP INC. S2 2-43568-0 AMP INC. S1 3-43568-4 AUGAT S10-10-10-10-10-10-10-10-10-10-10-10-10-1	• • • •	********	* * *					
2 731511-201 1 STIFFEMER-LONG READ/WRITE CIPHER DATA PROD 3 731510-400 1 BAR STIFFEMER CIPHER DATA PROD 4 731501-300 4 RETAINER-P/C CONNECTOR CIPHER DATA PROD 5 735000-402 2 SPACER CIPHER DATA PROD 6 205026 37 TEST POINT .058 DIA PIN 6 205026 37 TEST POINT .058 DIA PIN 7 205088 1 CONNECTOR-12 POSH MOLEX, INC. 03-09-2121 00LEX, INC. 02-09-2134	1	754040-101	1	PWB-DATA, DUAL MODE	DIBBLE ELECTRONICS			* * * * * * *
A 731501-300 4 RETAINER-P/C CONNECTOR CIPHER DATA PROD	2	731511-201	1	STIFFENER-LONG READ/WRITE				
SPACER CIPHER DATA PROD	3		1	BAR STIFFENER	CIPHER DATA PROD			
6 205026 37 TEST POINT .058 DIA PIN			4	RETAINER-P/C CONNECTOR	CIPHER DATA PROD			
A					CIPHER DATA PROD			
205068								
ALT 205012 12 TERMINAL, MALE.093 DIA., PC 02-09-2134 NOT ON FILE 159-1050P FILE 1	•				MOLEX, INC.	P20		
TERMINAL-MALE,.093DIA,PC					MOLEX, INC.	(SEE-NOTE#136),P20		
10 211015-003 1 SWITCH-DIP,8POS,SEALED SWITCH-DIP,7POS,SEALED AMP INC. S1				TERMINAL-MALE,.093DIA,PC	NOT ON FILE			
11 211015-002 1 SWITCH-DIP,8POS,SEALED AMP INC. 2-435668-8 11 211015-002 1 SWITCH-DIP,7POS,SEALED AMP INC. 52 12 211015-001 1 SWITCH-DIP,4POS,SEALED AMP INC. 53 13 211011-014 11 SOCKET,14 PIN LOW PROFILE AUGAT XA1-10,XU111 ALT 205025-514 SOCKET-DIP, 14 CONTACTS AUGAT 514-AG39D 14 731006-800 1 LABEL-ASSY CIPHER DATA PROD 15 211011-016 1 SOCKET,16 PIN LOW PROFILE AUGAT XU90 ALT 205025-516 SOCKET-DIP, 16 CONTACTS AUGAT XU90			2	CONNECTOR-29 POSN	WINCHESTER ELECTRONICS	P21,22		
12 211015-001 1 SWITCH-DIP,7POS,SEALED AMP INC. 2-435668-7 13 211011-014 11 SOCKET,14 PIN LOW PROFILE AUGAT XA1-10,XU111 ALT 205025-514 SOCKET-DIP, 14 CONTACTS AUGAT 514-AG10D CIPHER DATA PROD 15 211011-016 1 SOCKET,16 PIN LOW PROFILE AUGAT XU90 ALT 205025-516 SOCKET-DIP, 16 CONTACTS AUGAT XU90 ALT 205025-516 SOCKET-DIP, 16 CONTACTS AUGAT XU90			1	SWITCH-DIP, APOS, SEALED	AMP INC.	S1		
12 211015-001 1 SWITCH-DIP,4POS,SEALED AMP INC. 3-435668-4 13 211011-014 11 SOCKET,14 PIN LOW PROFILE AUGAT XA1-10,XU111 ALT 205025-514 SOCKET-DIP, 14 CONTACTS AUGAT 14 731006-800 1 LABEL-ASSY CIPHER DATA PROD 15 211011-016 1 SOCKET,16 PIN LOW PROFILE AUGAT XU90 ALT 205025-516 SOCKET-DIP, 16 CONTACTS AUGAT 216-AG39D AUGAT			1	SWITCH-DIP,7POS,SEALED	AMP INC.	S2		
13 211011-014 11 SOCKET,14 PIN LOW PROFILE AUGAT XA1-10,XU111 ALT 205025-514 SOCKET-DIP, 14 CONTACTS AUGAT 514-AG10D 14 731006-800 1 LABEL-ASSY CIPHER DATA PROD 15 211011-016 1 SOCKET,16 PIN LOW PROFILE AUGAT XU90 ALT 205025-516 SOCKET-DIP, 16 CONTACTS AUGAT AUGAT			1	SWITCH-DIP,4POS,SEALED	AMP INC.	S3		
14 731006-800 1 LABEL-ASSY CIPHER DATA PROD 15 211011-016 1 SOCKET-DIP, 16 CONTACTS AUGAT 216-AG39D ALT 205025-516 SOCKET-DIP, 16 CONTACTS AUGAT AUGAT 216-AG39D	13	211011-014	11	SOCKET,14 PIN LOW PROFILE	AUGAT	XA1-10,XU111		
CIPHER DATA PROD 15 211011-016 1 SOCKET,16 PIN LOW PROFILE AUGAT XU90 ALT 205025-516 SOCKET-DIP, 16 CONTACTS AUGAT	ALT	205025-514	;	SOCKET-DIP, 14 CONTACTS	AUGAT	,		
15 211011-016 1 SOCKET,16 PIN LOW PROFILE AUGAT XU90 216-AG39D ALT 205025-516 SOCKET-DIP, 16 CONTACTS AUGAT	14	731006-800	1 1	LABEL-ASSY				
ALI 203023-318 SUCKET-DIP, 16 CONTACTS AUGAT	15	211011-016	1 9	GOCKET, 16 PIN LOW PROFILE				
	ALT	205025-516	S	SOCKET-DIP, 16 CONTACTS	AUGAT			

	PARTS		040-00	OTK.RAW (NO SPEED KIT)	REV AJ ECO# 13977	08-20-82 (PRIN	TED: 08-20-82) PAGE 2 140 LINES	
	07V C	THEN TO MINE	ER OF	PARTS OR LENGTH OF MATERIAL	. IN FEET			
	ITEM	CIPHER	QTY	DESCRIPTION 1	MFG-NAME NFG-PART#	REF-DES	ST-DATE END-DATE	
		PART #		DESCRIPTION 2				
		*******		*******	*************			
	16	201191-063	5	CAPACITOR-ALUM WITH EPOXY END SEAL,22UFD,6.3V	PANASONIC CO. ECEBOJV220SR	C67,82,95,104,127		
	17	201121-680	9	CAP, DM, 68PF, 300V, 5%	SANGANO	C30,31,36,37,45,46,		
	7.			•	D153E680J0	51,52,58 C1,2,4,8,9,15,17,20,		
٠,,	18	201105-101	21	CAP, CER DISC, . 1UF, 10V,	CENTRALAB	22,25,40,55,96,99,		٠
	,,		•		UK10-104	107,108,109,110,111,		
				5.		116,126		
	•	•				C3,C11,C12,C16		
	19	201103-100	4	CAP CER .001UF 1000V GMV	SPRAGUE	Cajerriore		
	,	**************************************			5HK-D10	C5,6,13,14,18,19,23,,		
	20	201105-010	35	CAP, CER, DISC, . 01UF, 500V	SPRAGUE			
	**		,		5HKS-S10	24,38,39,53,54,59,60, 62,63,65,66,68,69,71,		
					•			
	:					72,74,75,77,78,80,81,		
						83,84,86,87,89,90,98		
	21	201122-150	. 1	CAP DM 150PF 300V 5%	SANGANO	C7		
		thirt	•		D153E151J0	010		
	22	201121-300	1	CAP,DM,30PF,300V,5%	SANGANO	C10		
	++.		•	•	D153C300J03	/4 /4 70 70 74 79 85.		
	23	201121-200	9	CAP DM 20PF 300V 5%	SANGANO	61,64,70,73,76,79,85,		
	FA		•		D153E200J0	88,91		
•	24	201121-270	9	CAP DM 27PF 300V 5%	SANGAMO	C117,118,119,120,121,		
	27	2000	,	•	D153E270J0	122,123,124,125		
	25	201105-103	1	CAP-CER DISC,.1UF,25V	SPRAGUE	C93		
	E.J	201103 100	-	•	563CY5SBA250AH104Z	201		
	26	201160-100	1	CAP TANT 1UF 35V 10%	NATIONAL COMPONENT IND.	C94		
	ĻO	141100 111	•		CS13BF105K	400 401 40E 104		
	27	201191-025	5 5	CAPACITOR-ALUM WITH EPOXY	PANASONIC CO.	C97,100,101,105,106		
	£1	LUIT/I UL-	•	END SEAL, 10UFD, 25V	ECEBIEV100SR	-		
	20	201104-50	1 1	CAP-CER DISC, . 05UF, 20V, 5%	CENTRALAB	C103		
	28	COLLOA 30	• -	2 2	UK20-503			
	20	201122-22	n	CAP DM 220PF 300V 5%	SANGAMO	C112,113		
	29	CALIEE - EE	• •		D153E221J0			
	, 55	201121-22	0 2	CAP DM 22PF 300V 5%	SANGAMO -	C114,115		
	30	ZOLIEL-EE	· -		D153E220J0			
	94	200074-33	0 3	RES FC 33.00K 1/4W 5%	NOT ON FILE	R30,32,37		
	31	_ £000/7 30	- 4	· · · · · · · · · · · · · · · · · · ·	RCRO7G333JM			
				4	•	4		

2N6034 200073-430 1 RES FC 4.30K 1/4W 5% NOT ON FILE R283 RCR07G432JM 40 210915 12 FERRITE BEAD FERRONICS, INC. L1,2,3,4 21-170J .7 WIRE BUS TND COPPER 22AWG 41 208500-298 ALPHA WIRE CORP. L1,2,3,4,A-B,F-G 298 1 RES FC 6.80K 1/4W 5% 42 200073-680 NOT ON FILE R284 RCR07G682JM 200073-270 19 RES FC 2.70K 1/4W 5% NOT ON FILE R16,53-56,85-88,125-RCR07G272JM 128,161-164,189,196 200204-005 9 POT-10K CERMET BOURNS INC. R203-211 3386P-1-103 200073-330 1 RES FC 3.30K 1/4W 5% NOT ON FILE R13 RCR07G332JM 9 RES-FC,390 OHM,1/2W,5% 46 200082-390 NOT ON FILE R224,228,236,241,243, RCR20G391JM 247,248,252,256 27 RES FC 470 OHM 1/2W 5% 200082-470 NOT ON FILE R233,225,227,229,231, RCR20G471JM 233,235,237,239,240, 242,246,249,251,253, 255,257,222,226,230, 238,245,254,250,232, 234

OTY GIVEN IS NUMBER OF PARTS OR LENGTH OF MATERIAL IN FEET ITEM CIPHER OTY DESCRIPTION 1 MFG-NAME REF-DES ST-DA PART # DESCRIPTION 2 MFG-PART#	ATE END-DATE
ITEM CIPHER QTY DESCRIPTION 1 MFG-NAME REF-DES ST-DA	ATE END-DATE
UADT W	*****
48 200075-220 1 RES FC 220.00K 1/4W 5% NOT ON FILE R1 RCR07G224JM	
49 200072-220 2 RES FC 220 OHM 1/4W 5% NOT ON FILE R2,297	
RCR07G221JM	
P3.4.5.9.10.17.18.19.	
50 200074-100 22 RES FC 10.00K 1/4W 5% NUT UN FILE 34,60,66,100,106,136, RCR07G103JM 34,60,66,100,106,136, 142,172,178,197,217,, 219,262,285	
51 200072-390 1 RES FC 390 OHM 1/4W 5% NOT ON FILE R6	,
51 200072-390 1 RES FC 390 OHM 1/4W 5% NOT ON FILE 100 NOT ON	
TO TAKE 10 10 PEC EC 400 OUM 1/4U 57 NOT ON FILE R7,8,45,48,77,80,117,	
52 200072-680 13 RES FC 680 UHM 1/4W 3% NOT ON FILE 120,153,156,187,258,, RCR07G681JM 259	
53 200073-470 25 RES FC 4.70K 1/4W 5% HOT ON FILE R11,46,47,49,50,78,	
54 200074-240 1 RES FC 24.00K 1/4W 5% NOT ON FILE R12 RCR07G243JM	
NOT ON TITE PAA.70.104.110.140.	
55 200073-150 10 RES FC 1.50K 1/4W 5% NOT ON FILE K64,70,104,110,140, RCR07G152JM 146,176,182,201,220	
56 200075-150 1 RES FC 150.00K 1/4W 5% NOT ON FILE R14 RCR07G154JH	
57 200075-430 1 RES FC 430.00K 1/4W 5% NOT ON FILE R15 RCR07G434JM	
58 200075-510 3 RES-FC,510K,1/4W,5% NOT ON FILE R20,21,25 RCR07G514JM	
59 200074-470 8 RES FC 47.00% 1/4W 5% NOT ON FILE R22,23,24,31,33,35, RCR07G473JM 36,38	
60 200072-330 1 RES FC 330 OHM 1/4W 5% NOT ON FILE R298 RCR07G331JM	
61 200073-510 1 RES FC 5.10K 1/4W 5% NOT ON FILE R29 RCR07G512JM	

PAR L	IST	154040-0			ASSY-DA' RAW (NO		•		R
QTY GIV	EN IS	NUMBER OF	PART	S OR	LENGTH	OF M	ATERIAL	IN	FEET

OTY C	TUEN TS NIME	ER NF	PARTS OR LENGTH OF MATERI				
ITEM	CIPHER PART #		DESCRIPTION 1 DESCRIPTION 2		· REF-DES	ST-DATE	END-DATE
• • • •	• • • • • • • • • •	* * *		******************	•••••	* * * * * * * *	
62	200074-150	27	RES FC 15.00K 1/4W 5%	NOT ON FILE RCR07G153JN	R39,42,61,62,67,68, 71,74,101,102,107, 108,111,114,137,138, 143,144,147,150,173, 174,179,180,192,198, 199,		
63	200074-220	18	RES FC 22.00K 1/4W 5%	NOT ON FILE RCR07G223JM	R40,41,43,44,72,73, 76,75,112,113,115, 116,148,149,151,152, 185,186		
64	200073-100	20	RES FC 1.00% 1/4W 5%	NOT ON FILE RCR07G102JM	R28,51,58,59,83,90, 93,97,99,123,130,133, 135,159,166,169,171, 188,194,295		
65	200073-220	18	RES FC 2.20K 1/4W 5%	NOT ON FILE RCR07G222JM	R52,57,84,89,124,129, 160,165,190,286,287, 288,289,290,291,292, 293,294		
66	200071-470	9	RES FC 47 OHM 1/4W 5%	NOT ON FILE RCRO7G47OJM	R63,65,103,105,139, 141,175,177,200		
67	200076-100	18	RES FC 1.00MEG 1/4W 5%	NOT ON FILE RCR07G105JM	R69,91,92,94,95,96, 98,109,131,132,134, 145,167,168,170,181, 195,202		
68	200071-750	2	RES FC 75 OHM 1/4W 5%	NOT ON FILE RCRO7G750JM	R183,184		
69	200073-200	2	RES FC 2K 1/4W 5%	NOT ON FILE RCRO7G202JM	R212,264		
70	200073-300	1	RES FC 3,00K 1/4W 5%	NOT ON FILE RCRO7G302JN	R213		
71	200071-150	1	RES-FC,15 OHMS,1/4,5%	NOT ON FILE RCRO7G15OJM	R214		
72	200071-100	1	RES FC 10 OHM 1/4W 5%	NOT ON FILE RCR07G10OJM	R263		
73	200066-150	9	RES-FC,1.5 MEG,1/8W,5%	ANY ACCEPTABLE SOURCE RCR05G155JM	R265,268,269,272,273, 276,277,280,282		

		1040-0	OO9 PWB ASSY-DATA DUAL, 9TK,RAW (NO SPEED KIT) PARTS OR LENGTH OF MATERIA	REV AJ ECO# 13977	08-20-82 (PRINTED: 08-20-82) PAGE 140 LINES
• • • •			THE TAKE OF PERSON OF BRIEFITS			
ITEM	CIPHER Part #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE END-DATE
• • • •	********	• • •	******************	*********************	*******	*** ******* ******
74	200066-680	9	RES-FC,6.8 MEG,1/8W,5%	ANY ACCEPTABLE SOURCE RCR05G685JM	R266,267,270,271,2	74,
75	205255	1	RESISTOR NETWORK-220/330	BECKMAN INSTRUMENTS, INC. 899-5-R220/330	275,278,279,281 U111	
76	203027-001	1	IC-QUAD 2-INP POS-AND GT	TEXAS INSTRUMENTS SN74LSO8N	U1	
77	203046-001	2	IC-RTRIG NAST HLTV	TEXAS INSTRUMENTS SN74LS123N	U2,115	
78	203095-500	1	IC-13INPUT POS NAND GATE	TEXAS INSTRUMENTS SN74LS133N	U4	
79	203029-027	1	IC-TRIPLE THREE INPUT POSITIVE NOR GATE *	TEXAS INSTRUMENTS SN74LS27N	U5	
80	203042-501	2	IC-4-BIT BIN CNTR	TEXAS INSTRUMENTS SN74LS93N	U7,U11	
81	203051-174	1	IC, HEX D-TYPE FLIP FLOP	TEXAS INSTRUMENTS SN74LS174N	U8	
82	203036	1	IC-QUAD 2-INP POS-NND BFR	TEXAS INSTRUMENTS SN7438N	U9	
83	203026	1	IC-HEX INVERTER	TEXAS INSTRUMENTS SH7404N	U10	
84	203048-100	3	IC-SYN,4-BIT COUNTER	NATIONAL SEMICONDUCTORS DM74LS161N	U12,15,91	
85	203046-132	1	IC-QUAD, 2 INPUT, POS-NAND-TRIG	TEXAS INSTRUMENTS SN74LS132H	U13	
86	203010	1	IC-DUAL OPERATIONAL AMPL	SIGNETICS N5558V	U16	
87	203026-003	1	IC-TTL HEX INVERTER POS NAND (OPEN COLLECTOR)	TEXAS INSTRUMENTS SN7405N	U17	
88	203039-001	6	IC-DUAL-D FLIP-FLOP	TEXAS INSTRUMENTS SN74LS74N	U18,26,38,49,61,75	
89	203085-001	8	IC-SCHM, TRIG INPUT, HEX IV		U21,25,36,48,59,71, 112,113	
90	203023	1	IC-QUAD 2-INP POS-NAND GT	TEXAS INSTRUMENTS SN7400N	U22	
91	203010-001	1	IC-VOLTAGE COMPARATORS	NATIONAL SENICONDUCTORS LM2903N	U23	

QTY GIVEN	IS	NUMBER	0F	PARTS	OR	LENGTH	OF	MATERIAL	IN	FEET	
-----------	----	--------	----	-------	----	--------	----	----------	----	------	--

•				(C
		4040-0	9TK, RAW (NO SPEED KIT	RÈV AJ ECO# 13977)	08-20-82 (P	RINTED: 08-20-82) PA
QTY G	IVEN IS NUM	BER OF	PARTS OR LENGTH OF MATERIA	AL IN FEET		140 LINES
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE END-DATE
* * * *	*******	• • •	***************	******************	***************	** ******* ******
92	203029-003	4	IC-TRIP,3-INPUT AND GATE	TEXAS INSTRUMENTS SN74LS11N	U24,47,70,114	
93	203007-350	9	IC-VOLT COMP/BFR	NATIONAL SEMICONDUCTORS LM319N	U27,32,39,44,50,55, 62,74,69	
94	203026-600	4	IC-TTL HEX,INVERTER POS NAND (OPEN COLLECTOR)	TEXAS INSTRUMENTS SN74LS05N	U28,40,51,63	
95	203007-351	9	IC-VOLTAGE COMPARATOR	NATIONAL SEMICONDUCTORS LM311N	U29,30,41,42,52,53, 64,65,77	
96	203130	9	IC-JFET INPUT OP AMPS	TEXAS INSTRUMENTS	U33,34,45,46,56,57, 66,67,79	
97	203042-001	6	IC-QUAD EXCLUSIVE OR GATE	TEXAS INSTRUMENTS SN74LS86N	U37,60,76,108,109,1	10
98	203043-500	9	IC-OP AND HI PERFORMANCE	TEXAS INSTRUMENTS SN72709P	U80-88	
99	203046-002	1	IC-TTL DUAL VOLTAGE CONTROLLED OSCILLATOR	TEXAS INSTRUMENTS SN74S124N	U89	
ALT	154040-701		HEADER ASSY-VOLTAGE CONTROLLED OSCILLATOR	CIPHER DATA PROD		
100			•			
101	203026-500	1	IC-HEX INVERTER BFR/DRVR	MOTOROLA SEMI. MC7406P	U92	
102	203082-500	6	IC-HEX BUFF/DRIVERS	TEXAS INSTRUMENTS SN7407N	U93-98	09-01-82 L*140
103	203042-800	9	IC-DUAL J-K FLIP-FLOP	TEXAS INSTRUMENTS SN74LS112N	U99-107	
104	203032-501		IC-TTL QUAD,2INP,POS-NOR 'BUFFER,,O/C	TEXAS INSTRUMENTS SN7433	U35,58,,73	
105 106	203023-001	5	IC-QUAD 2-INP POS-NND GT	TEXAS INSTRUMENTS SN74LSOON	U31,54,68,73,43	
	203013-300	1	EC-VOLTAGE REGULATOR, -12V,1.5 AMP	MOTOROLA SENI. MC7912CP	VR1	
108	203013-210	1	IC VOLTAGE REGULATOR	MOTOROLA SENI. MC7812CP	VR2	
109	209991-002	10	INDUCTOR-2.7UH,+-20%	DALE ELECTRONICS, INC. IR-4	L5-14	

PARTS LIST	154040-009	PWB ASSY-DATA DUAL,	REV	AJ ECO# 13977	08-20-82	(PRINTED: 08-20-82)	PAGE 8
		ARY DAN (NO ODDAN VIN)				140 IINFS	

PARTS		1040-00)9 PWB ASSY-DATA DUAL, 9TK,RAW (NO SPEED KIT) PARTS OR LENGTH OF MATERIA		08-20-82 (P)	140 L	
			TAKIS UK LENGIN UP NHIEKIN				
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	******	• • •	******************	*************************	***************	• • • • • • • • • • • • • • • • • • • •	* * * * * * * *
110	210145	1	HEAT SINK	IERC PA2-1CB	XVR2		
111	205061-004	8	WASHER FLAT FIBRE	SMITH, HERMAN H. 2191			
112	210030-171	4	STANDOFF 1/8 2-56 HEX BR	AMATOM ELECTRONIC HDW 8100-B-0256			
113	213271-405	5	SCREW-PAN HD PHIL, 4-40 X 5/16,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE			
114	213271-407	3	SCREW-PAN HD,PHIL, 4-40 X 7/16,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE			v
115	213271-409	4	SCREW-PAN HD PHIL, 4-40 X 9/16,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE	·		
116	207406-081	6	NUT, HEX, RADIO PAT. #4	ANY ACCEPTABLE SOURCE NUT #4 CAD.			
117	207408-021	12	WASHER, FLAT, SMALL OD #4	ANY ACCEPTABLE SOURCE			
118	207403-011	12	WASHER, SPLIT LOCK #4	ANY ACCEPTABLE SOURCE WASHER #4 CAD.		•	
119				•			
120			•				
121	210260-003	1	WASHER-LOCK, DISHED TYPE,	SHAKEPROOF 4706-06-01			
122	211000-325	4	SOCKET-TERMINAL	AUGAT LSG-2DG8-1	XC21,XC92		
123	211000-200	1	SOCKET-ASSEMBLY, CRYSTAL	AUGAT 8000-DG1	XY1		
124							
125	209100-552	.15	TUBING TFL 22 GA	ALPHA WIRE CORP. TFT-200/22-NAT	4114 * 5414		
126							
127	210806-500	1	SWITCH-PUSH BUTTON, NOM	ROOD SWITCH RS5035	S4		

		54040-(IBER 01	009 PWB ASSY-DATA DUAL, 9TK,RAW (NO SPEED KIT F PARTS OR LENGTH OF MATERI	REV AJ ECO# 13977) Al in efet	08-20-82	(PRINTED: 08-2 140	0-82) PAGE 9 Lines
ITEM	CIPHER PART #		DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	* * * * * * * * * *	* * *	************	*********	* * * * * * * * * * * * * * * * * * *	**** ******	
128	208500-605	1	WIRE-JUMPER, INSULATED	SQUIRES ELECTRONICS 0.500X0.125PVC22			
129			1	V13VVXV11Z3FVLZZ			
130	354040-300	REF	SCHEMATIC-DATA, DUAL MODE	CIPHER DATA PROD			
131	- 134 ARE	BLANK	•				
135 136 137 138	* (NO SPEE) * * DO NOT	D KIT Inter	FOR 154040-009) HIX TERMINALS ITEM #8 (2050	12) & ALT PART (205012-001)	IN ONE CONNECTOR		
139	******	*****	X X X X Y Y Y Y Y Y Y Y Y Y Y Y Y Y Y Y				
			***********	**********	*******	***	
140	203030-417		IC-HEX BFR/DRIVER	TEXAS INSTRUMENTS SN7417N	U93-98	L*102	08-31-82

PARTS	LIST 154	040-6	08 SPEED KIT-125 IPS	REV B ECO# 4315	09-29-78 (PRIN	TED: 07-31-80) PAGE 1 5 LINES OF 1
TTEM	CIPHER PART #	стү	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE END-DATE
					* * * * * * * * * * * * * * * * * * * *	******* ******
1.	154040-408	5	HEADER ASSY	CIPHER DATA PROD	A1,2,3,4,5	
2	154040-416	5	HEADER ASSY	CTPHER DATA PROD	A6,7,8,9,10	
3	201213-018	1	CAP-CER,1800PF,100V,10%	AVX CERAMICS CK05BX182	C21	
4	201121-561	1	CAP-DM,56PF,500V,5%	SANGAMO CMOSFD560J03	C92	
5	210111-512	1	CRYSTAL-QUARTZ,6.400 MHZ	STANDARD CRYSTAL CORP. 815-A-6.400 MHZ	Y1	

		1004-(REV C ECO# 7489	05-19-80 (PRIN	TED: 05-19-80) PAGE 1 8 LINES OF 1
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE END-DATE
• • • •	*******	• • •	••••••	********************	****************	******
1	754004-201	2	SHELL-CAPSTAN	CIPHER DATA PROD		
2	75 4004-302	1	HUB-CAPSTAN	CIPHER DATA PROD		
3 4						
5	210201-902	1	RING. TOLERANCE	ROLLER BEARING CO., AMER. ANO37025		
6 7			•		e e	
8	209990-107	AŘ	CONTACT CEMENT-PERMABOND	PEARL CHENTCAL CO. 101	•	

....

PARTS	LIST 154	0040	01 CAPSTAN ASSY	REV C ECO# 7489	05-19-80	CPRIN	TED: 05-19 ALIN	
ITEM	CIPHER PART #	фтү	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES -		ST-DATE	END-DATE
		* * *	*****************			• • • • •	* * * * * * * *	******
1.	754004-201	2	SHELL-CAPSTAN	CIPHER DATA PROD				
2	754004-301	1	HUB-CAPSTAN	CIPHER DATA PROD				
3 4 5	210201-901	1	RING, TOLERANCE	ROLLER BEARING CO., AMER. ANO31025				
6 7 8	209990-107	AR	CONTACT CEMENT-PERMABOND	PEARL CHENICAL CO. 101				

•

PARTS	LIST 155	5005-0	01 SWITCH PANEL ASSY	REV D ECO# 8271	0913-80 (FKI)	4TED: 01-13 14 L3	
TLEM	CIPHER PART #	aty	DESCRIPTION 1 DESCRIPTION 2	MEG-NAME MEG-PART#	REF-DES	ST-DATE	END DATE
* * * *	* * * * * * 1 * * *	+ 0 +		******************	* * * * * * * * * * * * * * * * * * * *		• • • • • •
1	154005-001	1	FWB ASSY-SWITCHES	CIPHER DATA PROD			
2	154011-201	1.	SWITCH ASSY-THUMBWHEEL	CIPHER DATA PROO			
3	755018-701	1.	HASHER-CORK	CIPHER DATA PROO	·•		
4	799017-201	2	SPRING-BELLEVILLE *	CIPHER DATA PROO			
5	`755005-101	1,,	SWITCH PANEL.	CIPHER DATA PROO			
6	153018-601	1.	SWITCH ASSY-VAC SENSE, ODOR INTERLOCK	CIPHER DATA PROO			
7	754019-701	1	LABEL-SHITCHES	CIPHER DATA PROO			
8	213271-212	1	SCREW-PAN HD PHIL, 2-56 X 3/4, CAD, BLK, ZINC	ANY ACCEPTABLE SOURCE			
9	213151-404	4	SCREW-FL HD FHIL, 100, 4-40 X 1/4, CAD, BLK, ZINC	ANY ACCEPTABLE SOURCE			
10	207202-021	1	WASHER, FLAT #2			•	
11	211051-575	1	SWITCH POWER, ON-NONE-OFF	WASHER, \$2 CAD. CARLINGSWITCH INC TA201-T			
12	207000-065	1	NUT-HEX, LIGHT THIN, 2-56	ESNA 22 NTK-26			
13	205000-000	1	PIN,GROOV-3/64X3/16	GROOV-PIN GP1-046X0187-12			
14	210229-523	1	TY-RAP-1/16 TO 5/8	ICO RALLY			

PARTS	1 TST 15	5001-8	01 DOOR ASSY-DUST COMER	REV C ECO# 4520	11-13-78 (PRI)	₹7ED: 01-11 12 LT	
LTEM	CIPHER PART #	, CITY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	*******		******************		*****************		* * * * * * * *
1	755001-701	1	DOOR-DUST COVER	UL-BOLERO PLASTICS			
2			•				
3	731920-900	1	LATCH-DUST DOOR	CIPHER DATA PROD			
4 5	799003-800	2	HINGE - FLAT 1 X 1	CIPHER DATA PROD			
6 7	211113-600	7.5	TAPE-FLAME RETARDANT POLYURETHANE	BURNETT & CO. UNIFOAM N S82N			,
8 9	213062-408	2	COSSILLOS AND CAZO	AND ACCOUNTAGE OF COMPOSIT	•		
Ą	STORE TOO	á.	SCREW-BTN HD SKT, 4-40 X 1/2, BLK ONLY	ANY ACCEPTABLE SOURCE			
1.0	213062-605	4		ANY ACCEPTABLE SOURCE			
11	•						
1.2	207408-021	2	NASHER, FLAT, SMALL OD #4	ANY ACCEPTABLE SOURCE			

•

			101 COVER ASSY-COLUMN,SIDE		03-29-79		:D: 01-11 14 LT	ande of t
Matc	C) PHER PART #	(311	DESCRIPTION 1 DESCRIPTION 2	MFG-PART#	REF-DES	· ·	ST-DATE	ERO-DATE
* (* 0	(* * * * * s t t		* * * * * * * * * * * * * * * * * * * *	*******	* * * * * * * * * * * * * * * * * *			
1.	75 5002-70)1 1	COVER-SIDE COLUMN	CIPHER DATA PROD				
2	755016-10)1 1	FACADE-COLUMN*SUPPLY	CIPHER DATA PROD				
3	755002-90)1 1	GLASS-SIDE COLUMN	CIPHER DATA PROD				
4	Z13005-Z0	10 2	HINGE-DUST DOOR	CIPHER DATA (200)				
5			•					
6	205289-00	11 3	LATCH - GROMMET *	HARTHELL CORP.				
7	205289-00	2 3	LATCH - FLUNGER	HN4G-44-1 HARTWELL CORP. HN4P-44-4-1				
8	- 10 ARE	ELANK.		1041,11-1-1				
1.1	213062-40	4 4	SCREW-ETN HD SKT, 4-40 X 1/4 BLK	A. AOVA (ARES ACV)				
12	209990-80	0 AR	ADHESIVE-STRL, SYN RESIN	4-40X1/4"BLACK MINNESOTA MINING 3520 B/A				
ALT	209990-30	0		MINNESOTA MINING 2216 B/A CLEAR AMBER				
13	209990-07	2 AR		LOCTITE 222				
14	210040-09	6 104	CORD-NEOPRENE,1/16 DIA	ROYAL IND, SEE CAT SHEET				
ALT	210040-09	5	and the second s	ROYAL (ND. SEE CATALOG SHEET				

PARTS	LIST 155	016-5	01 COVER ASSY-COLUMN, BOTT	[*] 04	REV	В	ECO:	¥ 4548	12-15-78	(PRIN	TED: 01 13	L.Th	ı:S	PAGE 1 OF 1
TTEM	CIPHER PART #	йтү	DESCRIPTION 1 DESCRIPTION 2	* * * * *	MFG-	PAR	T#	• • • • • •	REF-DES		ST-DAT	E	END-D	ATE:
* * * *	* * * * * * * * * *			* * * * * *	• • • • •	• • •	• • • •		******			• •		, , ,
1	755002-601	1	COVER-COLUMN, BOTTON	CIPHER	R DATA	PR	COD							
2	755016-601	İ	FACADE-COLUMN, TAKEUP .	CIPHER	R DATA	PR	:00							
3	755002-901	1	GLASS-SIDE COLUMN	CIPHER	R DATA	PR	(00)							
4	713005-700	. 2	HINGE-DUST DOOR	CIPHEN	R DATA	e PR								
5 7	205289-001	3	LATCH - GROMMET *	HARTUI HN4G-4		ORF •	•							
7	205289-002	3	LATCH - PLUNGER *	HARTW HN4P-4			•							
8	- 10 ARE E	BLANK.	•				•							
1.1	213062-404	4	SCREW-BTN HD SKT. 4-40 X 1/4 BLK	4-40X	1/4°Bl	_ACI	〈	,						
12	209990-800	AR	ADHESIVE-STRL, SYN RESIN	MINNE 3520		COOP	ENG		`				•	
ALT	209990-300		ADHESIVE-STRL, MOD EPOXY	MINNE 2216	B/A CI			ER			`			
13	209990-072	AR	ADHESIVE-LOCTITE *	LOCTI 222	TE		•							

PARTS	LIST 154	1014-8	01 RACK MTG, HARDWARE	REV B ECO# 8360	100680	(PRINTED:	01-10 10 L.T		GE = 1
TEM	CIPHER PART #	ety.	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART₽	REF TDES		DATE	END-DATE	
* * * *	********	• • •	• • • • • • • • • • • • • • • • • • • •		* * * * * * * * * * * * * * * * * * * *	• • • • • • • • • • • • • • • • • • • •			
1	154014-901	1.	HINGE BLOCK ASSY	CIPHER DATA PROD	· ·				
2									
3	154014-902	1	HINGE BLOCK ASSY	CIPHER DATA PROD					
4	731002-300	1	SAFETY BLOCK, TOP PLATE	CIPHER DATA PROD					
5									
	213021-112	6	SCREW-BDR HD SLOT, 10-32 X 3/4,CAD,ELK,ZINC	ANY ACCEPTABLE SOURCE					
7	213091-408	1	SCREW-SKT HD CAP 4-40 X 1/2,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE					
8	210028	2	WASHER, FL, NYL, #10X.062 TK	AMATOM ELECTRONIC HDW 2319-N194					
. 9	209998-066	1	POLY BAG-3MIL+3 X 6	RICO FLASTIC 3 X 6	ı				
10	211200-160	1	LABEL-MOUNTING HARDWARE 2" X 3"	ANY ACCEPTABLE SOURCE ORDER BY DESC					

•

i

•

•

PARTS LIST 155072-001 PWB ASSY-CONTROL/SERVO REV N ECO# 14667 12-07-82 (PRINTED: 12-08-82) PAGE 1 313 LINES OF 17

		072-0 BER OF	O1 PWB ASSY-CUNTRUL/SERVU PARTS OR LENGTH OF MATERIA	L IN FEET	12-07-82 (PKI	313 L	
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
* * * *	*****				************	* * * * * * * * *	* * * * * * * * *
1	754072-101	1	PWB-CONTROL/SERVO	CIPHER DATA PROD			
2 3							
4	154013-901	6	IDCTR ASSY, SERVO FILTER	CIPHER DATA PROD	. L1-6		
5	154014-001	1	IDCTR ASSY, P.S. FILTER	CIPHER DATA PROD	19		
6	154014-002	2	IDCTR ASSY, P.S. FILTER	CIPHER DATA PROD	17,8		
7	154014-201	2	XFMR ASSY, P.S. FILTER	CIPHER DATA PROD	T2,3		
8	154014-202	1	XFMR ASSY, P.S. FILTER	CIPHER DATA PROD	T1		
9	154014-301	1	XFMR ASSY-SWITCHING RGLTR	CIPHER DATA PROD	T4		
10	799015-501	3	TRANSFORMER-900X SERVO	CIPHER DATA PROD	A1-3		
11 12	205026	58	TEST POINT .058 DIA PIN	AMP INC. 60802-2	TP1-50,52-59		
13			'				
14 15	155033-812	1	SOFTWARE ASSY-920X	CIPHER DATA PROD	U56		
16	79400/ 000		TADEL ACCV	CIPHER DATA PROD			
17	731006-800	1	LABEL-ASSY	CIFRER DATA FROD			
18	731501-300	2	RETAINER-P/C CONNECTOR	CIPHER DATA PROD			
19	760003-301	1	STRUT-CONT/SERVO,FMTR	CIPHER DATA PROD			
. 20	210040-074	4	SPACER-ROUND,1/4 X 5/16,	NOT ON FILE 9225A140			
21	754014-401	9	MTG PLATE-COIL	CIPHER DATA PROD			

PARTS LIST 155072-001 PWB ASSY-CONTROL/SERVO REV N ECO# 14667 12-07-82 (PRINTED: 12-08-82) PAGE 2
313 LINES

QTY (GIVEN IS NUMB	ER OF	PARTS OR LENGTH OF MATERIA	AL IN FEET		313 L	INES
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
• • • •	* * * * * * * * * *	• • •	**************	****************	********		
22	754014-501	6	MTG PLATE-COIL	CIPHER DATA PROD			
23	754016-501	1	HEATSINK	CIPHER DATA PROD			
24	754016-701	1	INSULATOR-MYLAR HEATSINK	CIPHER DATA PROD			
25					•		
26	205133-001	. 2	CONNECTOR-3 PIN MALE	MOLEX,INC. 09-18-5032	P10,12		
27	205133-002	1	CONNECTOR-3 PIN	MOLEX, INC. • 09-18-5031	P29		
28 29	205133-033	2	CONN WAFER 3 PIN,PC	MOLEX, INC. 09-18-5033	P25,26		
30	205133-037	1	CONN WAFER 3 PIN,PC	MOLEX, INC. 09-18-9037	P27		
31	205133-051	1	CONN WAFER-5 PIN,PC	MOLEX,INC. 09-18-5051	F8		
32	205133-059	2	CONN WAFER-5 PIN,PC	MOLEX, INC. 09-18-5059	P4,5		
33	205133-950	1	CONN, WAFER 5 PIN, PC	MOLEX,INC. 09-18-5950	P30		
34	205133-951	1	CONNECTOR-WAFER SPIN PC	MOLEX, INC. 09-18-5951	P28		
35	205133-069	1	CONN WAFER 6 PIN,PC	MOLEX, INC. 09-18-5069	P14		
36	205133-094	1	CONN WAFER 9 PIN,PC	MOLEX, INC. 09-18-5094	P3		
37	205068	1	CONNECTOR-12 POSN	MOLEX,INC. 03-09-2121	F7		
38	205012	12	TERMINAL, MALE. 093 DIA., PC	MOLEX,INC. 02-09-2134	F7		
39 40				1	·		
41	201104-501	10	CAP-CER DISC,.05UF,20V,5%	CENTRALAB UK20,503	C109-112,10,11,36,37, 62,63		

						010 2	• · ·
QTY G	IVEN IS NUMB	ER OF	PARTS OR LENGTH OF MATERIA	L IN FEET			
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	******	• • •	2	******************	***************	* * * * * * * * *	
42	201105-100	7	CAP-CER DISC,.IUF,100V	MALLORY Tao10	C34,35,60,61,28,57,80		
43	201105-101	41	CAP-CER DISK,.1UF,10V	CENTRALAB UK10-104	C13,29-32,39,54-56, 58,65,81-85,103-106, 108,136,138-140,142, 155,170,180,183,184, 196,197,206,208-211, 213,216,193	1 2	
44	201105-103	23	CAP-CER DISC,.1UF,25V	SPRAGUE 563CY5SBA250AH104Z	C24,25,50,51,76,77, 107,121,141,181,4-7,		
ALT	201105-102		CAP-CER DISC,.1UF 25V 20%	CENTRALAB UK25-104	137,177,178,182,204, 205,202,214,215		·
45	201104-010	24	CAP, CER, . 001UF, 50V, 10%	CENTRALAB CW15C102K	C14-21,40-47,66-73		
46	201105-010	1	CAP-CER, DISK, . 01UF, 500V	SPRAGUE 5hks-s10	C156		
47	201121-470	1	CP-DM 47PF 300V 5Z	CORNELL-DUBILIER ELECT. CD15EC470J03	C187	٠	
48	201122-100	8	CAP-DM 100PF 300V 5%	SANGAMO D153E101J0	C12,38,64,120,122, 123,134,173		
49	201122-200	1	CAP-DM 200PF 300V 5%	SANGAMO D153E201JO	C9		
50	201122-470	1	CAP-DM 470FF 300V 5%	SANGAMO D153E471J0	C125		
51	201122-680	1	CAP DM 680PF 300V 5%	SANÇAMO D153E681J0	C3		
52	201123-151	1	CAP-DM,1500PF,100V,5%	CORNELL-DUBILIER ELECT. CD7FA152J03	C98		
53	201122-150	2	CAP-DM 150PF 300V 5%	6ANGAMO D153E151JO	C94,95		
54 55		1	CAP-CER,.0015UF,600V, +-10%	CF-152	C157	. "	
56 57		2	CAP-DM 220PF 300V 5%	SANGAMO D153E221JO	C117,126		

		5072-0 BER OF	01 PWB ASSY-CONTROL/SERVO PARTS OR LENGTH OF MATERIA		12-07-82 (PRIN	ITED: 12-08 313 L	
TEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
• • •	*********	• • •		**************			
58	201226-205	6	CAPACITOR-MYLAR, 2. OUF, 200V, +-20%	EL PAC Z1A205K	C26,27,52,53,78,79		
59	201122-270	1	CAP-DM 270PF 300V 5%	SANGANO D153E271J0	*C171 // //	1.	
60	201144-120	2	CAP-PC .012UF 50V 20%	INB BA2-123	C168,119		
61	201149-018	i	CAF-PC,.018UF,50V,5%	EL PAC C5A183J	C192		
62	201148-150	3		EL PAC C5A154J	C116,131,147		
63	201148-330	۶.	CAP-PC .33UF 50V 5%	EL PAC C5A334J	C133,145,146,149,152,		•
64	201149-022	2	CAP-PC .0022UF 50V 5% 50V 5%	EL PAC C5A222J	169 C101,102		•
65	201149-047	6	·-	EL PAC C5A472J	C99,100,127,143,144,		
66	201149-100	3	CAP-PC .01UF 50V 5%	EL PAC	186 C8,97,200		
67	201149-220	4	CAP-PC .022UF 50V 5%	C5A103J EL PAC C5A223J	C1,2,148,153		
4.6	201140 200		045 56 ABAUM MAN MAN	OURTED!			

NOT ON FILE

* C5A393J

EL PAC

C5A473J

EL PAC

C5A683J

C5A912J

EL PAC

EL PAC

C5A224J

WMF2D22

EL PAC

C5A333J

650B1A105-Ğ

CORNELL-DUBILIER ELECT.

ELECTRO CUBE, INC.

C128

094

C129,130

C190,191

C22,23,48,49,74,75,

C113,114,115,118

C33,59

150,151

C194,195

201149-390

201149-470

201149-680

201148-220

201159-022

201149-330

75 201140-001

71 201149-091

72

73

1 CAP-PC .039UF 50V 5%

1 CAP-PC .047UF 50V 5%

2 CAP-PC .068UF 50V 5%

2 CAP-PC .22UF 50V 5%

2 CAP-PC .033UF 50V 5%

4 CAP-PC, 1UF, 50V, 2%

2 CAP-PC,.0091UF,200V,5%

8 CAP-MYLAR,0022UF 200V 10%

PARTS	LIST 155	072-00	1 PWB ASSY-CONTROL/SERVO	REV N ECO# 14667	12-07-82 (PRI	TED: 12-08-82) PAGE 5 313 Lines
QTY GI	VEN IS NUMB	ER OF	PARTS OR LENGTH OF MATERIAL	IN FEET	•	
ITEM	CIPHER PART #	OTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE END-DATE
	********		***********	**************		******
76	- 78 ARE B	LANK.			,	
79						
80			•			
81	201191-063	6	CAPACITOR-ALUM WITH EPOXY END SEAL,22UFD,6.3V	PANASONIC CO. ECEBOJV22OSR	C135,158,166,167,185, 201	
82	201148-470	1	CAP-PC .47UF 50V 5%	EL PAC C5A474J	C132	·
83	201161-220	1	CAP-TANT 22UF 15V 10%	NATIONAL COMPONENT IND. CS13BD226K	C154	
84	201191-025	7	CAPACITOR-ALUM WITH EPOXY END SEAL,10UFD,25V	PANASONIC CO. ECEBIEV100SR	C161,162,172,174,175, 203,207	
85			END SERESTOOLD 1234	•		
86	201172-101	1	CAP-ELECT, 100UF, 150V	CORNELL-DUBILIER ELECT. WBR100-150	C159	
87	201173-050	1.	CAP-ELECT 500UF 10V A/L	SPRAGUE 39D507G010EJ4	C160	
88	799500-095	2	CAP-ELECT,1000UF,25V (SPEC CONTROL DWG) *	CIPHER DATA PROD	C163,164	
89	201173-200	1	CAPACITOR-ELECT, 2000UF, 10	ELECTRA/MIDLAND CORP 39C10FJ23	C165	
90	- 93 ARE	BLANK.	•			
	210112		CRYSTAL 3.84MHZ	STANDARD CRYSTAL CORP. 817-A-3.840MHZ	Y1	
95 96	202009	2	DIODE RECTIFIER,1 AMP	MOTOROLA SEMI.	CR119,120	
97	202011-744	1	DIODE-ZENER, SILICON	1N4001 THRU 1N4004 MOTOROLA SENI.	CR105	
98	202013-718	50	DIODE-HOT CARRIER	1N4744 GENERAL INSTRUMENT OPTO IN5817	CR9-24,37-52,65-80, 109,111	02-01-83 L*312
ALT	202013-819	,	DIODE-HOT CARRIER	GENERAL INSTRUMENT OPTO IN5818		

99 - 105 ARE BLANK.

PART	5 LIST 15:	5072-0	01 PWB ASSY-CONTROL/SERVO	REV N ECO# 14667	12-07-82 (PRI	NTED: 12-08-82) 313 LINES	PAGE
QTY		BER OF	PARTS OR LENGTH OF MATERIA	L IN FEET		V10 111110	
IŢEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	'REF-DES	ST-DATE END-D	
* * * *	********	* * *	**************	* * * * * * * * * * * * * * * * * * * *	*************	*******	
106	202018	37	DIODE, SWITCHING	TEXAS INSTRUMENTS IN914	CR1-8,29-36,57-64,94- 99,101,102,104,106, 108,118		
107	202019	3	DIODE-ZENER, 6.8V	FAIRCHILD In957B	CR103,107,110		
108	202034	2	DIODE-RECT FAST RECOVERY	MOTOROLA SEMI.	CR116,117		
109	202035	' 4	RECTIFIER-POWER	MOTOROLA SEMI. MR851	CR112-115	·	
110	202005-500	12	RECTIFIER-PWR, HI EFF, 6A	UNITRODE CORP. UES1302	CR25-28,53-56,81-84		
111	203052-051	1	IC-MULTIPLXR,8 CH	MOTOROLA SEMI. NC14051BCP	U37		
112 113	203052-053	. 5	IC-MULTIPLXR,TRIPLE 2 CH	MOTOROLA SEMI. MC14053BCP	U77,57,50,67,68		
114							
115 116	203007-200	1	IC-OPER.AMPL	NATIONAL SEMICONDUCTORS	U2		
117	203007-600	1	IC-OPER AMPL/BUFFER	NATIONAL SEMICONDUCTORS LM324N	U27		
118	203007700	9	IC-VOLTAGE COMPARATOR	NATIONAL SEMICONDUCTORS	U6,7,13,14,20,21,29, 39,95	·	
119	- 122 ARE	BLANK	•	•			
123	203008-741	1	IC OP AMP	NATIONAL SEMICONDUCTORS	U1		
124	203012-136	14	IC-QUAD OPER AMPLIFIERS	TEXAS INSTRUMENTS RC4136	U5,12,19,26,30-33,38, 46,64-66,76		
125	- 129 ARE	BLANK	y .		10101 00110		
130	203023	1	IC-QUAD 2-INP POS-NAND GT	TEXAS INSTRUMENTS SN7400N	U3		
131	203013-210	2	IC VOLTAGE REGULATOR	MOTOROLA SEMI. MC7812CP	VR1,2		

				* *** ****			
			PARTS OR LENGTH OF MATERIA				
TEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
• •		• • •			**************		
132	203013-300	2	EC-VOLTAGE REGULATOR, -12V,1.5 AMP	MOTOROLA SEMI. MC7912CP	VR3,4		
133 134 -	203023-001	1	IC-QUAD 2-INP POS-NND GT	TEXAS INSTRUMENTS SN74LSOON	U83	•	
135	203046-001	1	IC-RTRIG MNST MLTV	TEXAS INSTRUMENTS SN74LS123N	U98		
136	203024 .	4	IC-QUAD 2-INP POS-NOR GT	TEXAS INSTRUMENTS IC-SN7402N	U8,15,22,79		
137	203026	, 1	IC-HEX INVERTER	TEXAS INSTRUMENTS SN7404N	U88		
138	203026-500	1	IC-HEX INVERTER BFR/DRVR	MC7406P	U89		
139	203027	5	IC-QUAD 2-INP POS AND GT	TEXAS INSTRUMENTS SN7408N	U10,17,24,82,99		
	203027-001	1	IC-QUAD 2-INP POS-AND GT	TEXAS INSTRUMENTS SN74LSO8N	U52		•
	203029-003		IC-TRIP,3-INPUT AND GATE	TEXAS INSTRUMENTS SN74LS11N	U11,18,25 U70		
	203035-032		IC,QUAD 2 INPUT POSORGATE	TEXAS INSTRUMENTS SN74LS32N	U41,42		
	203036		IC-QUAD 2-INP POS-NND BFR	SN7438N			
144	203039-001		IC-DUAL-D FLIP-FLOP	TEXAS INSTRUMENTS SN74LS74N	U4,59,78,92		
145	203046-132		IC-QUAD, 2 INPUT, PQS-NAND-TRIG	TEXAS INSTRUMENTS SN74LS132N	U60		
146	203046-148		IC,3-8 LINE DECODER	TEXAS INSTRUMENTS SN74LS138N	U91,93		
147	203046-153		IC,4-1 LINE SEL/MLTP	TEXAS INSTRUMENTS SN74LS153N	U80		
148	203051-174		IC, HEX D-TYPE FLIP FLOP	TEXAS INSTRUMENTS SN74LS174N	U40,51,58,69,81,90		
149	203051-100		IC-QUAD D-TYPE FLIP-FLOP	TEXAS INSTRUMENTS SN74LS175N	U53		
150	203052-253	4	IC,4-1 LINE SEL/MLTP	TEXAS INSTRUMENTS SN74LS253N	U44,55,62,71		

PARTS LIST 155072-001 PWB ASSY-CONTROL/SERVO REV N ECO# 14667 12-07-82 (PRINTED: 12-08-82) PAGE 8

QTY	GIVEN IS NUM	BER O	F PARTS OR LENGTH OF MATER:	IAL IN FEET		313 1	
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
• • • •	********	• • •		****************	***********	* * * * * * * *	
151			IC-SCHM, TRIG INPUT, HEX IV	SN741 S14N	U54,61		
152	203123	1	IC-REG PULSE WIDTH MODULA	TEXAS INSTRUMENTS SG3524N	U97		
153	200072-910	1	RES-FC 910 OHM 1/4W 5%	NOT ON FILE RCR07G911JM	R234		
154	203545-102	2	IC-MEMORY MOS RAM 256 X 2	SILICON GENERAL 2111A	U84,85		
155	203555-101	1	IC-CONTROL, MOS	ZILOG Z8430PS	U72		
156	203575-101	1	IC-MICRO PROCESSOR, MOS	ZILOG Z-80 CPU	U86		
157	203039	1	IC-DUAL D-TYPE FLIP-FLOP	TEXAS INSTRUMENTS	U87		
158	200074-360	1	RES-FC 36.00K 1/4W 5%	SN7474N NOT ON FILE	R294 .	•	
159	200200-101	1	POT-TRIMMING,1K	RCR07G363JM BQURNS INC. 3299X-1-102	R367		
ALT	200200-102		POT-TRIMMING,1K	SPECTROL			
160	200204-200	3	POT 20K CERMET	64X102T000 Electra/Midland Corp Et34P203	R242-244		
161	200205-052	5	POT-TRIMMING, 50K	BOURNS INC. 3006P-1-503	R188-191,250		
	200070-470	14	RES-FC,4.70HMS,1/4W, 5%	NOT ON FILE RCRO7G4R7JM	R37-40,89-92,142-145,	r	
163	200071-100	1	RES-FC 10 OHM 14W 5%	NOT ON FILE RCRO7G100JM	403-404 R370		
164	200071-150	2	RES-FC,15 OHMS,1/4,5%	NOT ON FILE RCRO7G15OJM	R210,408	•	
165	200071-470	3	RES-FC 47 OHM 1/4W 5%	UOT OU DIES	R194,195,409		
.66	200073-910	3	RES-FC 9.1K,1/4W 5%	Und ou been	R24,459,468		
67	200072-100	1	RES-FC 100 OHM 1/4W 5%	HOW DIE BYEN	R400		

CINHI	F191 133	0/ L W	V1		•	313 L	INES
OTY G	IVEN IS NUMB	ER OF	PARTS OR LENGTH OF MATERIA	L IN FEET	•		
ITEM	CIPHER PART #	YTO	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
		• • •		***********	***************		* * * * * * * * *
168	200072-220	b	RES-FC 220 OHM 1/4W 5%	NOT ON FILE RCRO7G221JM	R8,170-173,355		
169	200074-110	1	RES-F 11.00K 1/4W 5%	NOT ON FILE RCRO7G113JM	, R77		
170	200072-330	14	RES-FC 330 OHM 1/4W 5%	NOT ON FILE RCRO7G331JM	R21,22,26,27,71,72, 78,87,123,124,130, 140,353,356		
171	200072-470	2	RES-FC 470 OHM 1/4W 5%	NOT ON FILE RCRO7G471JM	R6,7		
172	200072-560	24	RES-FC 560 OHM 1/4W 5%	NOT ON FILE RCRO7G561JM	R29-36,79-86,131-134, 136-139		
173	200072-680	2	RES-FC 680 OHM 1/4W 5%	NOT ON FILE RCRO7G681JM	R351,352		
174	200072-750	2	RES-FC 750 OHM 1/4W 5%	NOT ON FILE RCR07G751J#	R357,358		
175	200072-430	2	RES-FC 430 OHM 1/4W 5%	NOT ON FILE RCR07G431JM	R347,348		
176	200122-750	1	RES-WW,750 OHMS,3.75W,5%	DALE ELEC. INC. CW-2B .1-9K	R379		
177	200073-820	1		NOT ON FILE RCRO7G822JM	R470 R385		
178	200073-220	1	,	NOT ON FILE RCRO7G222JM	R380,462		
179	200073-680	2	RES-FC 6.80 1/4W 5%	NOT ON FILE RCRO7G682JM	R1,270,384,391,402,	•	
180			RES-FC 1.00K 1/4W 5%	NOT ON FILE RCRO7G102JM	406,426,484,485 R28,88,141		
181		3	RES-FC 1.10K 1/4W 5%	NOT ON FILE RCR07G112JM	RED JOO J. V.		
182		_		NOT ON FILE	R196-199,342,343,397		
183			RES-FC 1.50K 1/4W 5%	RCRO7G152JM NOT ON FILE	R211		
184		_	RES-FC 1.80K 1/4 5%	RCRO7G182JM NOT ON FILE	R2,292,328,334,399,		
185	200073-200) 7	RES-FC 2K 1/4W 5%	RCRO7G202JM	427,436		

	-				-				-	-
3	1	3	L	I	N	E	S			

QTY G	IVEN IS NUMB	ER OF	PARTS OR LENGTH OF MATERIA	L IN FEET	•	-	
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	• • • • • • • • •	* * *		***************************************	* • • • • • • • • • • • • • • • • • • •		* * * * * * * *
186	200073-240	5	RES FC 2.40K 1/4W 5%	NOT ON FILE RCR07G242JM	R271,272,338,428,429		
187	200073-300	2	RES-FC 3.00K 1/4W 5%	NOT ON FILE RCR07G302JM	R3,4		
188	200073-270	1	RES-FC 2.70K 1/4W 5%	NOT ON FILE RCRO7G272JM	R377		
189			·				
190	200073-430	6	RES-FC 4.30K 1/4W 5%	NOT ON FILE RCR07G432JM	R291,293,327,329,332,		
191	200073-470	21	RES-FC 4.70K 1/4W 5%	NOT ON FILE RCRO7G472JM	R9,18,20,25,73-75, 125-127,178,192,193,		
			<u> </u>		260,266,278,339,378, 398,433,438		
192	200073-510	3	RES-FC 5.10K 1/4W 5%	NOT ON FILE RCR07G512JM	R301,304,461	•	
193	200073-750	6	RES FC 7.50K 1/4W 5%	NOT ON FILE RCR07G752JM	R17,19,69,70,121,122		
194	200074-390	1	RES-FC 39,00K 1/4W 5%	NOT ON FILE RCRO7G393JM	R434		
195	200074-100	28	RES-FC 10.00K 1/4W 5%	NOT ON FILE RCRO7G103JM	R11,16,181,233,262, 265,267,269,298,300, 302,359,360,362,365, 366,369,374,375,376,		
				•	330,392,407,331,437, 425,303,289		
196	200074-120	5	RES-FC 12.00K 1/4W 5%	NOT ON FILE RCRO7G123JM	R129,232,346,349,354		
197	200074-150	14	RES-FC 15.00K 1/4W 5%	NOT ON FILE RCRO7G153JM	R176,200,201,206,207, 218,273,275,295,280, 413-415,432		
198	200074-180	7	RES-FC 18.00K 1/4W 5%	NOT ON FILE RCRO7G183JM	R471,473,474,475,477, 478,479	,	

PARTS LIST 155072-001 PWB ASSY-CONTROL/SERVU REV N ECO# 14667 12-07-82 (PRINTED: 12-08-82) PAGE 11

DTY C	TUPN TO NIMB	rp nr	PARTS OR LENGTH OF MATERIA	I IN PERT		313 L	INES
	*********	* * *	***** ON LENGIN OF MHIERIF	1L IN FGG1 ,	***************		
ITEM'	CIPHER PART #	OTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
• • • •	* * * * * * * * * * *	• • • •	*****************	*******************			******
199	200074-200	30	RES-FC 20.00K 1/4W 5%	NOT ON FILE RCR07G2O3JM	R67,68,119,120,202, 204,208,209,212,213, 246,247,263,455,456, 445,447,446,453,452,		
					457,442,440,451,450, 454,449,448,444,464	•	*
200	200074-220	12	RES-FC 22.00K 1/4W 5%	NOT ON FILE RCR07G223JM	R245,252,253,255,256, 258,264,268,283,285, 286,364		
201	200074-270	5	RES-FC 27,00K 1/4W 5%	NOT ON FILE RCR07G273JM	R274,284,463,465,469		
202	200074-330	8	RES-FC 33.00K 1/4W 5%	NOT ON FILE RCR07G333JM	R288,309,311,319,322, 393,476,472		
203	200074-580	2	RES-FC 56.00K 1/4W 5%	NOT ON FILE RCR07G563JH	R467,460		
204	200074-430	2	RES-FC 43.00K 1/4W 5%	NOT ON FILE RCRO7G433JM	R254,257	•	
205	200074-470	4	RES-FC 47.00K 1/4W 5%	NOT ON FILE RCR07G473JM	R5,10,231,279		
206	200074-510	2	RES FC 51.00K 1/4W 5%	NOT ON FILE RCR07G513JM	R287,481		
207	200074-680	3	RES-FC 68.00K 1/4W 5%	NOT ON FILE RCRO7G683JM	R58,110,314	,	
208	200074-750		RES-FC 75.0K 1/4W 5%	NOT ON FILE RCR07G753JM	R57,109,310,317,320, 321,390		
209	200015-121		RES-FF,121K,1/8W,1% MIL-R-10509 STYLE	R-OHM RN55D1213F	R226		
210	200075-100		RES-FC 100.00K 1/4W 5%	NOT ON FILE RCRO7G104JM	R177,313,318,340,363, 372		
211	200076-150		RES-FC 1.50MEG 1/4W 5%	NOT ON FILE RCRO7G155JM	R430,431		•
212	200075-150		RES-FC 150.00K 1/4W 5%	NOT ON FILE RCRO7G154JM	R312		
213	200075-200	1	RES-FC 200.00K 1/4W 5%	NOT ON FILE RCRO7G2O4JM	R373		
214	200075-220	7	RES FC 220.00K 1/4W 5%	NOT ON FILE RCRO7G224JM	R235,296,297,299,305, 315,316		

		BER OF	PARTS OR LENGTH OF MATERIA	AL IN FEET		313 I	INES
ITEM	CIPHER PART #	OTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
• • • •	*******	• • •	****************	*********	***********		
215	200015-174	1	RES-FF,174K,1/8W,1% MIL-R-10509 STYLE	R-QHM RN55D1743F	R214		
216	200075-270	2	RES-FC 270.00K 1/4W 5% -	NOT ON FILE RCRO7G274JM	R411,412		
217	200075-330	2	RES-FC 330.00K 1/4W 5%	NOT ON FILE RCRO7G334JM	R251,480		
218	200075-470	4	RES-FC 470.00K 14W 5%	NOT ON FILE RCRO7G474JM	R281,282,323,324		
219	200075-390	1	RS-FC 390.00K 1/4W 5%	NOT ON FILE (RCR07G394JM	R277		
220	200075-680	1	RES-FC 680.00K 1/4W 5%	NOT ON FILE RCRO7G684JM	R341		
221	200075-750	2	RES-FC 750.00K 1/4W 5%	NOT ON FILE	R56,108		
222	200014-715	1	RES-FF,71.5K,1/8W,1% MIL-R-10509 STYLE	RCRO7G754JM R-OHM RN55D7152F	R215		
223	200076-220	3		NOT ON FILE RCRO7G225JM	R205,259,203		
224	200013-196	1	RES-FF,1.96K,1/8W,1% MIL-R-10509 STYLE	R-OHM RN55D1961F	R422	•	
225	200076-470	5	RES-FC 4.70MEG 1/4W 5%	NOT ON FILE RCRO7G475JM	R23,128,182,183,76		
226	200077-200	2		NOT ON FILE RCRO7G206JM	R308,325		
227	200073-390	2	RES-FC 3.90K 1/4W 5%	NOT ON FILE RCRO7G392JM	R458,466		
228	200013-301	1	RES-FF,3.01K,1/8W,1% MIL-R-10509 STYLE	R-OHM RN55D3011F	R387		
229	200013-681	1	RES-FF,6.81K,1/8W,1% MIL-R-10509 STYLE	R-OHM RN55D6811F	R371		
230	200013-806	1	RES-FF,8.06K,1/8W,1% MIL-R-10509 STYLE	R-OHN	R368		
231	200014-909	1	RES-FF,90.9K,1/8W,1% MIL-R-10509 STYLE	RN55D8061F R-OHM	R386		
232	200013-221	2	RES-FF,2.21K,1/8W,1% MIL-R-10509 STYLE	RN55D9092F R-OHM RN55D2211F	R240,241		

PARIS	LIST 155	10/Z-U	OI LAND H291-CONTROL/25WAG			313 L	INES
TY G	TUEN IS NUME	ER OF	PARTS OR LENGTH OF MATERIA	L IN FEET			
TEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
	+++++++++			*********	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	* * * * * * * *	* * * * * * * *
200	000010 040	2	RES-FF,2.49K,1/8W,1%	R-OHM	R237,238,239		
233	200013-249	J	MIL-R-10509 STYLE	RN55D2491P	, ,		
234	200013-499	1	RES-FF,4.99K,1/8W,1%	R-OHM	R337		
			MIL-R-10509 STYLE	RN55D4991F	R14,15,61-64,113-116,		
235	200014-100	21	RES-FF,10.0K,1/8W,1%	R-OHM RN55D1002F	179,184,185,219,220,		
	÷		MIL-R-10509 STYLE	KUJJUIOSI	222,336,388,290,180, 221		
236	200014-127	1	RES-FF,12.7K,1/8W,1%	R-OHM	R248		
230	200017 127	•	MIL-R-10509 STYLE	RN55D1272F			
237	200014-200	2	RES-FF,20.0K,1/8W,1%	R-OHM	R217,229		
F0/	TOOL! TOO	_	MIL-R-10509 STYLE	RN55D2002F			
238	200014-301	5	RES-FF,30.1K,1/8W,1%	R-OHM .	R186,187,228,420,421		
		_	MIL-R-10509 STYLE	RN5503012F	5.5 AB 56 /5 444 449		
239	200014-536	6	RES-FF,53.6K,1/8W,1%	R-OHM	R12,13,59,60,111,112		
			MIL-R-10509 STYLE	RN55D5362F			
240	200015-100	4	RES-FF,100K,1/8W,1%	R-OHM	R65,66,117,118		
			MIL-R-10509 STYLE	RN55D1003F	5557 455		
241	200015-150	. 2	RES-FF,150K,1/8W,1%	R-OHM	R307,435		
			MIL-R-10509 STYLE	RN55D1503F	5000		
242	200014-309	1	RES-FF,30.9K,1/8W,1%	R-OHM	R230		
			MIL-R-10509 STYLE	RN55D3092F	0202 262		
243	200082-390) 2	RES-FC,390 OHM,1/2W,5%	NOT ON FILE	R382,383		
			•	RCR20G391JM	DD44 345		
244	200080-270) 2	RES-FC,2.7 OHMS,1/2W, 5%	NOT ON FILE	R344,345		
				RCR20G2R7JM	R41-43,45,46,49,50,		
245	200080-330	24	RES-FC,3.30HMS,1/2W,5%	NOT ON FILE	52,93-95,97,98,101,		
				RCR20G3R3JM	102,104,146-148,150,		
				•	151,154,157,155		
				une ou PILP	R44,47,48,51,96,99,		
246	200081-10	14	RES-FC,10 OHMS,1/2W,5%	NOT ON FILE	100,103,149,152,153,		
				RCR20G100JM	156,487,488		
				uom ou PTIP	R381,401		
247	7 200082-56	0 2	RES-FC 560 OHM 1/2W 5%	NOT ON FILE	101,401		
				RCR20G561JM	R389		
24	8 200084-10	0 1	RES-FC 10.00K 1/2W 5%	NOT ON FILE	R307		
				RCR20G103JM			

PART	S LIST 155	5072-	001 PWB ASSY-CONTROL/SERV	0 REV N ECO# 14667	12-07-82 (PRI	NTED: 12-08	-82) PAGE 14
		BER O	F PARTS OR LENGTH OF MATERI			313 L	
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	REF-DES	ST-DATE	END-DATE
* * * *	* * * * * * * * * * *	* * *	. * * * * * * * * * * * * * * * * * * *	***************	*************	*****	******
249	200128-100	7	RES-WW,.100HM,3.75W,5%	DALE ELEC. INC. CW-2B .1-9K	R54,55,106,107,159,		
250	200014-806	4	RES-FF,80.6K,1/8W,1% MIL-R-10509 STYLE	R-OHM RN55D8062F	160,405 R216,224,225,227		
251			RES-FF,33.2K,1/8W,1% MIL-R-10509 STYLE	R-OHM RN55D3322F	R174,175,223,236		
252	205255-500		RESISTOR NETWORK-220/330	BECKMAN INSTRUMENTS, INC. 898-5-R220/330	U43		
	205253		RESISTOR NETWORK-560 OHM	BECKMAN INSTRUMENTS, INC. 899-1-R560	U9,16,23		
	200015-301	1	RES-FF,301K,1/8W,1% MIL-R-10509 STYLE	R-OHM RN55D3013F	R306		
255			.				
256	211015-001	1	SWITCH-DIP, 4POS, SEALED	AMP INC. 3-435668-4	S1		
257	211011-016	1	SOCKET, 16 PIN LOW PROFILE	AUGAT 216-AG39D	XU43		
258	200080-100	1	RES-FC,1.0 OHMS,1/2,5%	ANY ACCEPTABLE SOURCE RCR20G1ROJM	R486		
259	211011-024	1	SOCKET,24 PIN LOW PROFILE	AUGAT 224-AG39D	XU56		
260	211011-028		SOCKET,28 PIN LOW PROFILE	AUGAT 228-AG39D	XU72		
	211011-040	1	SOCKET,40 PIN LOW PROFILE	AUGAT 240-AG39D	XUB6		
262 263	204027-014	24	TRANS-CORE DRVRS,NPN	TEXAS INSTRUMENTS	01-8,13-20,25-32		
244	799603-100	4	TRANSISTOR-NPN, SILICON, SELECTED	2N4014 CIPHER DATA PROD	Q39,40,42,43		
245	204017-950	1	TRANSISTOR, NPN-GENERAL PURPOSE	MOTOROLA SEMI. MPS2222	Q58		
266	204012	2	TRANSISTOR, PNP SILICON	WTVAS TUSTELLING	Q50,61		
267	204013	6	TRANSISTOR, NFN SILICON	TOVAS THEFT	037,38,41,49,59,60		

1 111111							
OTY G	IVEN IS NUMB	ER OF	PARTS OR LENGTH OF MATERIA	L IN FEET			
ITEM	CIPHER PART #	QTY	DESCRIPTION 1 DESCRIPTION 2	MFG-NAME MFG-PART#	KEL-DE2	ST-DATE	END-DATE
	*******	• • •	*********	********			••••
268	204016-913	2	TRANSISTOR, NPN SILICON	NATIONAL SEMICONDUCTORS 2N4013	Q54,55		
269	204027-034	4	TRANSISTOR P-N-P SILICON	MOTOROLA SEMI. 2N6034	045,48,52,53		
270	204027-037	3	TRANSISTOR N-P-N SILICON	MOTOROLA SEMI. 2N6037	Q46,47,51		
271	204028-500	12	TRANSISTOR-NPN, SILICON	MOTOROLA SEMI. 2N6338	09-12,21-24,33-36		
272	199650-201	1	TRANSISTORS-MATCHED	CIPHER DATA PROD	Q56,57		
273 274	209990-074	AR	ADHESIVE, NUT LOCK	LOCTITE 242			
275 276			·	ONDER ON THE COURSE			
277	213271-407	1	SCREW-PAN HD, PHIL, 4-40 X 7/16, CAD, BLK, ZINC	ANY ACCEPTABLE SOURCE			
278	213271-409	6	SCREW-PAN HD PHIL, 4-40 X 9/16,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE			
279	213271-607	4	SCREW-PAN HD PHIL, 6-32 X 7/16,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE			
280	213271-608	28	SCREW-PAN HD PHIL 6-32 X 1/2,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE			
281	213271-616	. 3	SCREW-PAN HD PHIL, 6-32 X 1,CAD,BLK,ZINC	ANY ACCEPTABLE SOURCE			
282	213274-132	2 3	SCREW-PAN HD PHIL CAD OR ZINC 10-32X2	ANY ACCEPTABLE SOURCE			
283	3 207102-051	. 3	NUT, HEX-LG PAT	ANY ACCEPTABLE SOURCE NUT #10 CAD.			
28	210168	2	LUG, SOLDER #6	SMITH, HERMAN H. 1416-6			
28	5 207104-021	1 6	WASHER, FLAT,#10	ANY ACCEPTABLE SOURCE WASHER #10 CAD.			
28	5 207403-011	1 6	WASHER, SPLIT LOCK #4	ANY ACCEPTABLE SOURCE WASHER #4 CAD.			
28	7 207406-081	1 3	NUT, HEX, RADIO PAT. #4	ANY ACCEPTABLE SOURCE NUT #4 CAD.			

PART	S LIST	155072-	001 PWB ASSY-CONTROL/SERV	O REV N	ECO# 14667	12-07-82 (P)	RINTED: 12-0	8-82) PAGE 16
QTY	GIVEN IS N	UMBER O	PARTS OR LENGTH OF MATERI	AL IN FEET			313	LINES
1776	OTBURE		DECEDENTAL 4	• • • • • • • • • • • • • • • • • • • •	• • • • • • • • •	*************		* * * * * * * * *
	PART #		DESCRIPTION 2	MFG-NAME MFG-PART	# .	REF-DES	ST-DATE	END-DATE
* * * *	******	** ***	******************	**********	******	************		*****
288	207408-0	21 7	WASHER, FLAT, SMALL OD #4	ANY ACCEPTABLE				
289	207602-0	11 / 35	WASHER, SPLIT LOCK #6	ANY ACCEPTABLE	SOURCE			
290	207604-08	B1 35	NUT-HEX RADIO PATTERN 6-32	WASHER #6 CAD. ANY ACCEPTABLE S	SOURCE			
291	207608-02	21 38	WASHER, FLAT, SMALL OD #6	NUT #6 CAD. ANY ACCEPTABLE S				
292	210875-40	01 14	INSULATOR-THERMALLY CONDUCTIVE (TO-3)	WASHER #6 CAD. BERQUIST	`		05-01-83	L*307
293	210613-05	50 5	INSULATOR-MYLAR	7403-09FR-05 THERMALLOY CO				
294	213700-60	9 33	WASHER-FLAT, NYLON, SH PAT 5610-46-62	43-77-2 SEASTROM				
295 296			3010 40-02	5610-46-62	•			
297	208430-90	7 17	WIRE-SOL 30AWG KYNAR 7"	SONIC WIRE SALES			,	
298	210408-01	6 ,5	TUBING-HEAT SHRINK,	KN-30-130-6-7" ICO RALLY		1		
299	208500-29	8 .8	WIRE BUS TND COPPER 22AWG	HIX-1/4 UL ALPHA WIRE CORP. 298		•		,
300	209100-55	2 .8	TUBING TFL 22 GA	ALPHA WIRE CORP.				
301	213274-12		SCREW-PAN HD PHIL 10-32 X 1-3/4	TFT-200/22-NAT ANY ACCEPTABLE S	OURCE			
302	210260-00		WASHER-LOCK, DISHED TYPE,	SHAKEPROOF				
303			" "	4706-06-01		•	•	
304	211000-325	5 4	SOCKET-TERMINAL	AUGAT	:	XR424,423		
305	355072-300	0 REF	SCHEM-PWB,CONTROL-SERVO	LSG-2DG8-1 CIPHER DATA PROD				
306	******	******	***********	**************************************	*******	******************** *		
307	210613	1 4	INSULATOR, MYLAR-T03	THERMALLOY CO 43-03-2			L*292	04-30-83
				The Wall In				

PARTS	LIST 155	072-00	D1 PWB ASSY-CONTROL/SERVO	REV N ECO# 14667	12-07-82 (PR)	INTED: 12-08 313 L	INES
QTY GI	VEN IS NUMB	ER OF QTY	PARTS OR LENGTH OF MATERIA DESCRIPTION 1	MFG-NAME	REF-DES	ST-DATE	END-DATE
	PART #	•••	DESCRIPTION 2	MFG-PART#	******	, ,,,,,,,,	* * * * * * * *
308	- 311 ARE	BLANK	•			*	01-31-83
312	202013-717	50	DIODE-HOT CARRIER	MOTOROLA SEMI. 1N5817	CR9-24,37-52,65-80, 109,111	L*98	01-31-03
ALT	202013-818		DIODE-HOT CARRIER RECTIFIER,30V,1A	MOTOROLA SEMI. 1N5818			
313		•			•		

